

MicroDS

“The motion solution”

INSTALLATION and USER’S GUIDE

Revision B – June 12

Revision	Date	Description	Updated Pages
A	June 2003	C27159-001	
B	June 2012	MicroDS Installation and User's Guide	

C27159-001 Revision B, June 2012

Suggestions, corrections and comments should be sent to:

Moog Italiana S.r.l.
Electric Division
Via Avosso 94
16015 Casella (Genova)
Italy

Moog Inc.,
East Aurora,
New York 14052,
USA.

Moog GmbH,
Hans Klemm Straße 11
D-71034 Boblingen,
Germany.

I1	TABLE OF CONTENTS and INTRODUCTION	
I1	TABLE OF CONTENTS and INTRODUCTION	2
I2	INTRODUCTION	5
I2.1	USING THE MANUAL	6
I2.2	Safety	8
I2.3	Declaration of Conformity (EC)	10
I2.4	CE Requirements	11
I2.5	LEGAL ASPECTS	12
SECTION 1 DESCRIPTION		1
1.1	INTRODUCTION	1
1.2	PRODUCT RANGE	1
1.3	GENERAL FEATURES	2
1.4	TECHNICAL DATA	4
1.4.1	General features	4
1.4.2	Interfaces	5
1.4.3	Recovery Circuit	7
1.5	CODES	8
1.6	OPTIONS	10
1.7	DIMENSIONS AND DRILLING JIG	11
1.8	CONNECTION CABLES	12
1.9	EXTERNAL FUSES	13
1.10	POWER DISSIPATION	13
1.11	SOFT START	14
1.12	FANS	14
1.13	RESET BUTTON	14
1.14	POWER LINKS AND CONNECTORS	15
1.14.1	Power input voltage connectors	16
1.14.1.1	24V Auxiliary voltage	17
1.14.1.2	Motor power connector	18
1.14.1.3	Mains Voltage Supply	19
1.14.1.3.1	SINGLE PHASE OPERATION	19
1.14.1.4	PARALLEL DC BUS OPERATION	20
1.15	Recovery circuit	20
1.16	CONTROL CARD LINKS AND CONNECTORS	23
1.16.1	Encoder input connector	24
1.16.2	Resolver input connector	28
1.16.2.1	G400 and G330 motors resolver wiring	32
1.16.3	Input References Connector	34
1.16.4	Drive enable connector	36
1.16.5	Encoder Connector (output)	38
1.16.6	RS485 Serial link	39
1.17	Drive Starting Sequence.	40
1.18	Dynamic Braking	42
1.19	MECHANICAL BRAKING	43

SECTION 2 INSTALLATION	1
2.1 INTRODUCTION	1
2.2 INSTALLATION REQUIREMENTS	1
2.3 ELECTROMAGNETIC COMPATIBILITY	3
2.3.1 EUROPEAN DIRECTIVE EMC (89/336/EEC)	3
2.3.2 FILTERING	4
2.3.2.1 Filter types	4
2.3.2.2 FILTERS MECHANICAL DIMENSIONS	5
2.3.2.3 Filter installation	6
2.3.3 Wiring and shielding	8
2.3.4 Recovery resistor	11
2.3.5 Shielding	11
2.3.6 Safety Aspects	12
2.4 Summary of Connection Instructions	13
2.4.1 Feedback connection (encoder or resolver)	13
2.4.2 "Temporary" / test power wiring	13
2.4.3 Summary of power wiring	14
SECTION 3 STARTUP	1
3.1 INTRODUCTION	1
3.2 DRIVE SETTING UP INFORMATION	1
3.3 First start-up (on test bench, for testing purposes)	3
3.4 Configuration for installation in the electrical cabinet.	3
SECTION 4 OPERATION	1
4.1 INTRODUCTION	1
4.2 GENERAL PRINCIPLES	1
4.2.1 Input electric power conversion	1
4.2.2 Output electric power conversion	2
4.2.3 Control section	2
4.2.4 High Speed operation	4
4.3 CONTROL LOOPS OPTIMIZATION	4
4.3.1 Current loop optimization	4
4.3.2 Speed loop optimization	5
SECTION 5 COMMANDS	1
5.1 DESCRIPTION	1
5.2 MOTOR PARAMETERS MENU	4
5.2.1 DESCRIPTION OF MOTOR PARAMETERS	5
5.2.1.1 Description of Resolver parameters	8
5.2.1.2 Description of Encoder Parameter	8
5.3 DRIVE PARAMETERS MENU	9
5.3.1 DESCRIPTION OF DRIVE PARAMETERS	10
5.4 CONTROL LOOPS PARAMETERS MENU	16
5.4.1 DESCRIPTION OF CONTROL LOOPS PARAMETERS	17
5.4.1.1 SPEED LOOP PARAMETERS	17

5.4.1.2	CURRENT LOOP PARAMETERS	18
5.5	Enable menu	19
5.5.1	Description of Enable Menu	19
5.6	DISPLAY VARIABLES MENU	20
5.6.1	Description of Display Variables menu	21
5.7	UTILITY MENU	23
5.7.1	Description of Utility, Configuration Analog Out Sub Menu	24
5.7.2	Description of Utility, Parameter Sub menus	26
5.7.3	Description of UTILITY, Phasing & Save Program Sub Menu	27
5.7.4	Description of UTILITY, OFFSET sub MENU	29
5.8	Keyboard Lock Menu	30
5.8.1	Description of Keyboard Lock/Unlock Menu	30
5.9	FAULT MENU	31
5.9.1	Description of Fault Menu	31
SECTION 6 CONTROL LOOPS		1
6.1	INTRODUCTION	1
6.2	CURRENT LOOP	1
6.3	SPEED LOOP	1
6.4	ADDITIONAL CONTROL STRUCTURES	2
6.4.1	Soft-start Control	2
6.4.2	Recovery resistor control circuit	2
6.5	Additional Drive Data	3
6.5.1	Output current from the DC Bus connection	3
6.5.2	Max Recovery Current on MicroDS Drives	3
SECTION 7 TROUBLESHOOTING		1
7.1	INTRODUCTION	1
7.2	Faults on drive power supply circuit	2
7.3	Faults on output section	3
7.4	Faults on feedback section	4
7.5	Control loops trouble	5
Appendix A : Warranty		1
Appendix B : Motors technical data		2
Appendix C : Special Motors		4

I2 INTRODUCTION

Introductory note:

This manual details the MicroDS. This drive is a product line extension of the present DS2000 "The Motion Solution" drive range. Thus, functionally, these drives are almost identical. Some differences exist in the dynamic braking/recovery resistor functionality and various other functions which are detailed in the following chapters.



CAUTION: Repairs or modifications to the product by anyone other than a Moog authorized repair facility may create unsafe operating conditions and will invalidate the product warranty.

I2.1 USING THE MANUAL

This user's manual is intended to provide sufficient information on how to install, wire and tune a Moog brushless electric motor system. This user's guide must be read and understood before applying power and operating the equipment described.

This equipment must be installed and serviced only by duly qualified service personnel. All information in this manual is directed towards such persons only. Individuals responsible for the installation of the equipment described in this user's guide must ensure;

- 1) only technically qualified individuals are employed to work on the installation,
- 2) these qualified individuals must have the accompanying documentation available at all times when working on the installation and are obliged to use this documentation in a consistent manner, and
- 3) work on, or close to, the installation is prohibited for non-technically qualified individuals

After installation and before starting up the motor it is also recommended to check all system parameters to ensure correct system configuration.

Particular attention must be paid to all safety instructions.

NOTES:

Moog assumes no responsibilities for errors or omissions due to the information in this manual.

This manual is subject to changes at any time and Moog is not obliged to inform users of manual updates

The information in this manual is subject to revision due to product modifications and/or improvements. The manual can differ from previous manual versions.

I2.2 Safety

The safety instructions provided in this Manual are included to prevent injury to personnel (WARNINGS) or damage to equipment (CAUTIONS).




WARNINGS serve to make personnel aware of potentially hazardous actions that may result in personal injury or death.




CAUTIONS are to alert personnel to actions that could cause equipment damage, resulting in the equipment becoming unsafe.




CE-Compliance indicates where a particular application-related safety or EMC requirement is driven by the need for CE-Compliance of the MicroDS when installed in the system. Customers who do not need CE-Compliance on their machinery may choose not to implement these features.



WARNING: DO NOT remove or replace any assemblies, subassemblies or components with primary power present.



WARNING: Lethal voltages ($\geq 790V_{dc}$) remain present within this equipment when the mains power is removed. It is recommended to refrain from commencing any servicing, maintenance, repair or upgrading of this equipment until at least **five minutes** after power shutdown. It is further recommended to measure the voltage level at all high voltage terminals before commencing any such activities, to ensure that no lethal voltages are present.




WARNING: The removable plug-in connectors of the MicroDS Drives are for ease of wiring installation. These removable plug-in connectors are not suitable for connection or disconnection under power. All connections must be made with power removed.



WARNING: Repair or internal adjustments to the MicroDS Series Controllers must not be attempted. All faulty items must be returned to Moog Service Centres for maintenance and repair.



WARNING: High Voltage. The recovery resistor is connected to the Drive DC Bus and can have voltage $\geq 790V_{dc}$.



WARNING: Do not touch recovery resistor during operation to avoid burns.



CAUTION: Ensure that the correct input voltage, 230V or 400V, has been set.



CAUTION: If an emergency stop is required, opening U-V-W pins and closing motor phases to resistors, must be preceded by disabling the axis. The delay time must be at least 30 ms.



CAUTION: In case of repeated on/off switching, wait 1 minute between power removal and subsequent reapplication.



CAUTION: Cooling air to the MicroDS must be kept clean. The air supply must not contain particles that may deposit causing obstruction to airflow. It is recommend to periodically check the airflow.



CAUTION: Do not exceed the tightening torque values given in the following table. See Section 2 of this Manual for the recommended tightening torque of the terminal blocks

Screw Thread	Tightening torque	
	[Nm]	[lb in]
M3	1.00	8.85
M4	3.00	26.55
M5	6.00	53.10
M6	8.00	70.80
M8	20.0	177.0

12.3 Declaration of Conformity (EC)

Moog Ltd. • Ringaskiddy, County Cork, Ireland
Telephone: 353 (21) 4519000 • Telefax: 353 (21) 4519001

MOOG

EC - Declaration of Conformity

(Low Voltage Directive 73/23/EEC, EMC Directive 89/336/EEC)

Moog Ltd.,
Ringaskiddy,
Co. Cork,
Ireland.

Declare under our sole responsibility that the products:

MicroDS motor Controller, Model T360xx03x-xxx xxx
MicroDS motor Controller, Model T360xx06x-xxx xxx

To which this declaration relates are in conformity with the following standards or other normative documents

EN61800-3 1996	EMC
EN61800-3 /A11 2000	Electrical Safety
EN50178 1997	

Following the provisions of the EMC Directive 89/336/EEC and the Low Voltage Directive 73/23/EEC.

This product is CE marked in 2003

Issued by: Patrick Roche
Place of Issue: Ringaskiddy, Co. Cork, Ireland.
Date of Issue: 8 May 2003.

Legally Binding Signature.....



This declaration certifies compliance with the indicated directives but implies no warranty of properties.
The safety instructions of the accompanying product documentation shall be observed.

Irish Vat No. IE4576325F. Incorporated with Limited Liability in Zug, Switzerland Number 170.3.000.003.087
Director: P. Studer (Swiss)

I2.4



CE Requirements

- **Protection against electric shock.** Electronic Equipment intended for installation in closed electrical operating areas should be kept locked. Authorized person shall only open the lock and access should only allowed to skilled persons while the drive is energized. Where the equipment requires manual intervention, 412.2.1 of HD 384.4.41 S2 shall be consulted.
- **Fixed connection for protection.** The equipment may have a continuous leakage current of more than A.C. 3.5 mA or D.C. 10 mA in normal use. The MicroDS must be permanently and reliably connected to Earth and all conductive parts in the IP54 rated enclosure or cabinet must be permanently connected to Earth. The impedance between the earth terminal and any accessible part of the enclosure or cabinet should be less than or equal to 0.1 Ω .
- **External DC Supply Voltage Sources.** All external d.c. supply voltages used with the T200 Series Controllers must be derived from a Safety Extra Low Voltage (SELV) supply as defined by standard EN60950. Such SELV voltages do not exceed a value of 60 Vd.c. or 42.4 Va.c. peak under normal conditions and are supplied by circuits which are separated from all hazardous voltage conductors by permitted safety methods such as reinforced insulation.
- **RCD.** A D.C component can occur in the fault current in the event of a fault connection to earth. Only a residual-current-operated protective device (RCD) of Type B is allowed. When the protection in installations with regard to indirect contact is achieved by means of an RCD, their appropriate function/combination shall be verified.
- **Climatic Conditions.** Equipment intended to operate within its performance specification over the range of Class 3K3, as defined in table 1 of EN 60721-3-1, EN 60721-3-2, EN 60721-3-3, EN 60721-3-4, partly modified.
- **Installation** - The MicroDS must be mounted in a vertical orientation. The MicroDS must be panel mounted within an enclosure or cabinet which provides a degree of ingress protection against liquids and objects of at least IP54. Such enclosures or cabinets must be accessible to technically qualified service or maintenance persons only.
- **EMC Requirements.** The installer of the equipment is responsible for ensuring compliance with the EMC standards that apply where the equipment is to be used. Product conformity is subjected to filters installation and to recommend procedures, detailed in this Manual.
- **Second Environment (EMC).** This equipment intended to be connected to an industrial low-voltage power supply network, or public network, which does not supply buildings used for domestic purposes (second environment, according to EMC

Standards). If connected to a low-voltage public network that supplies domestic premises (first environment), this product may cause radio interference in which case supplementary measures may be required.

- **Cable Shielding.** Shielding of some external cables is necessary to ensure compliance with EMC requirements. Details of these requirements are given in Section 1 and Section 2.
- The **Integral Motor Thermal Protection** signal shall be connected on the equipment, on T360 connectors J4/J5 (PIN 2-15/6-8), which accepts signals maximum 5.5 Vdc \pm 10%, 400 μ A. The ultimate result of this signal is to "Switch-OFF" the output of the Solid State Motor Controller and thereby "No-Power" is transmitted to the Motor connected to the Motor-Drive.

I2.5 LEGAL ASPECTS

This manual can only be used by final Customers/Users of the Moog product it describes.

This manual cannot be reproduced in whole or in part without prior written consent from Moog.

No distribution of this manual by electronic, mechanical, or printed means is allowed.

This manual has been issued with the intention of providing all information necessary to perform a complete installation of the MicroDS. Moog assumes no responsibility for errors or omissions contained herein and for incidental or consequential damages due to the above mentioned errors and omissions.

Moog reserves the right to change and update this manual without notice.

This manual is for information purposes only. Moog assumes no responsibility with regard to the correspondence of the product features described in the manual and the features on the actual product purchased by the final Customer/User.

No statement or sentence contained in this manual implies further legal obligations, different from those contained in each sale or supply contract regarding Moog products.

SECTION 1 DESCRIPTION**1.1 INTRODUCTION**

This manual describes the MicroDS drive series and provides information about the installation and the functional characteristics of the product.

This section describes MicroDS drive features and also refers to the ordering system.

1.2 PRODUCT RANGE

MicroDS is a digital drive for permanent magnet synchronous servomotors (hereafter: brushless). Vector control of asynchronous servomotors (hereinafter: asynchronous) is also possible.

The range is made up of 2 models, corresponding to 3 A_{rms} and 6 A_{rms} nominal currents.

The transducers available with the motor are either an incremental encoder or a resolver.

An internal recovery resistor is provided in the drive. An optional second external recovery resistor is also available.

The Moog GUI software pack is available to manage, by means of a PC, both the drive configuration and the display of all internal values.

The manual together with the notes in the Appendices provides a complete description of the drive.

1.3 GENERAL FEATURES

The MicroDS features provide the automation industry with the best response to the most difficult requirements of motion control.

FULL DIGITAL:

- Speed and current control loops and many other functions such as the DC BUS status monitoring, soft-start and recovery circuit management and protection are implemented digitally to ensure reliable and flexible operation.

- The digital operation ensures maximum system stability and reliability over time, temperature and varying application conditions.

- Settings are carried out through values calculated in analytic models and do not depend upon potentiometric calibrations.

FLEXIBLE:

- Any brushless motor can be controlled by entering a maximum of 8 parameters which adjust the current loop and identify the motor electromechanical characteristics (peak current, Back EMF, inductance, resistance, number of poles, voltage rating, speed, feedback encoder pulses characteristics, resolver poles).

- The drive can control asynchronous motors by means of vector control. By entering the additional parameters, magnetization current (ID) and the slip gain (frequency), it is possible to use asynchronous motors. The remaining parameters related to the hardware features remain active.

- The motor position transducer can be either a resolver (with 2 to 24 poles) or an incremental encoder (from 1024 to 8192 pulses). For the resolver, internal hardware gain adjustment allows maximum resolution be achieved depending on the transform ratio of the resolver. The required gain setting should be specified (for FAS or Global motor) in the drive order code.

- It is possible to program the device in 2 different languages: Italian and English; the required language should be specified in the order code. At any time, using the GUI, it is possible to load a different language. Only one language can be active in the drive.

SECTION 1 : DESCRIPTION

- The input supply voltage can range from 65 VAC to 510 VAC three-phase.
Operation with a single-phase power supply is also possible with appropriate de-rating.

- Unlike the DS2000 models, it is necessary to supply 24V backup power at all times.

ADVANCED PERFORMANCE:

The current loop, based on a traditional PI structure, is provided with automatic compensation algorithms for the Back EMF and of the KP/KI ratio, as a function of the motor characteristics.

Hardware calibration is not necessary for the current loop.

Current loop update rate: 10kHz.

Speed Loop Update rate: 5kHz.

1.4 TECHNICAL DATA**1.4.1 General features**

Three-phase input voltage rating:	from 230V _{ac} to 460V _{ac} ±10%, 50/60 Hz
Single-phase Input voltage rating:	230Vac (Input Power limited to 1.1kW)
Min/max Three-phase input voltage:	65 / 510 V _{ac} (DC-Bus: 80 / 720 V _{dc})
Auxiliary voltage (required):	24 V _{dc} ±10% , 1A (SELV)
Configurable analog references:	from 3.2 to 10 V _{dc}
Recovery Resistor:	120□, 100W (6 Arms Drive) 120□, 50W (3 Arms Drive)
Max dynamic with encoder	200 Hz
Switching frequency:	10 kHz
Speed adjustment:	0 ÷ 9999 rpm
Anti-resonance low-pass filter:	20 ÷ 800 Hz
Filter on reference:	1 ÷ 800 Hz
Notch filter (programmable):	50 ÷ 1500 Hz
Ambient temperature:	0 ÷ +40 °C (exceeding Class 3K3)
Storage temperature:	-25 ÷ +55 °C (Class 1K4)
Transport temperature:	-25 ÷ +70 °C (Class 2K3)
Relative humidity:	5% to 85% (with no condensation and no formation of ice)
Environment:	For use in a pollution degree 2 environment.
Derating for altitude >1000 m:	1% every 100 m
Air Pressure	86 kPa to 106 kPa

1.4.2 Interfaces**- Analog**

- Speed (or current) reference differential input: 0 +/- 10V (adjustable scale)
- Auxiliary input voltage: $24V_{dc} \pm 10\%$, 1A
- Output Voltage: $15 \pm 10\% V_{dc}$, 100mA
- Analog output (configurable)
- Tachometric signal (adjustable scale)
- Peak current limit (via analog signal)
- Motor temperature (through PTC or NTC)
- Resolver interface

- Digital

- RS485 full-duplex serial link
- encoder input (incremental)
- encoder output (incremental)
- reset
- drive OK output
- drive enable input
- reference enable input

Drive front control panel




Fig 1.1 MicroDS Front Panel

Protection

- motor overtemperature
- drive overtemperature
- IGBT module current foldback
- input voltage out of tolerance
- bus overvoltage
- internal recovery resistor power limiting
- encoder or resolver signal missing
- encoder or resolver faulty connections
- axis short circuit (motor and recovery resistance output)
- Overspeed in torque mode control (if speed is 12% above max set value).

1.4.3 Recovery Circuit

Dynamic braking unit				
MicroDS		Standard recovery resistance (Internal)		
Model code	Currents (rms/pk)	Resistance and power	Max Current	Max Duty Cycle ¹
T360xx03x-xxx xxx	3/11	120Ω/50W (int.) ²	6.25	1.05%
T360xx06x-xxx xxx	6/22	120Ω/100W (int.) ³	6.25	2.1%

Tab 1.1 Recovery resistance data


¹ Operating with 600V DC Bus.

² An equivalent resistor of equal resistance and power rating (Order code: C25722-003-121) can be attached externally to the drive if required. For operation at 230V, a lower value resistance can be connected externally. Consult Moog sales office for further details.

1.5 CODES

The MicroDS can be ordered using the boxcar shown in Fig 1.2.

SECTION 1 : DESCRIPTION



Accessories:

Graphical User Interface (GUI) part number is CZ5300

RS232/422/485 Converter part number is CZ5200

Users manual is available @ www.moog.com

Note:

- 1) Users must be experienced/qualified in the use of this product range before building products from this drawing.
- 2) All drive options are provided with a 120Ohm Internal Regen Resistor
- 3) External regen resistors are to be ordered and supplied separately.

Fig 1.2 MicroDS Drive BoxCar

1.6 OPTIONS

Optional devices separately supplied are

- RS232/422/485 Converter (Moog code CZ5200)
- Moog GUI communication program (Moog code CZ5300)

1.7 DIMENSIONS AND DRILLING JIG

The following figures show the drives dimensions and details and drilling information for mounting the drive.




Fig 1.3 □A Size drive dimensions and drilling jig (in mm.)

1.8 CONNECTION CABLES

The following table shows the cables specification for each part of the drive.

Use Class 1 wire only

It is recommended to use copper (Cu) cables, 60/75°C, UL certified, with the cross sections indicated in the table.

	MicroDS Model		Notes
	□A Size		
	3/11	6/22	
Line power cable (no. of conductors x AWG)	3 x 14 AWG	3 x 14 AWG	EMC Filter required. See Section 2 for details.
Protective bonding cable (no. of conductors x. AWG)	1 x 6 AWG	1 x 6 AWG	
Motor power cable (no. of conductors x. AWG)	4 x 14 AWG	4 x 14 AWG	shielded
Recovery resistor cable (no. of conductors x. AWG)	2 x 14 AWG	2 x 14 AWG	shielded
24V power cable (no. of conductors x AWG)	2 x 14 AWG		4 Turns on Fairrite core. Schaffner p/n # 00443164151
Motor encoder cable (no. of conductors x. AWG)	16 x 22/20 AWG		shielded
Motor resolver cable (no. of conductors x AWG)	8 x 22/20 AWG		shielded

Tab 1.2 Dimensions of connection cables

Note: The DC Bus connection between drives has the same wire size as the Recovery resistor. It must also be shielded.

AWG	mm ²
22	0.3
20	0.5
18	0.8
16	1.3
14	2.1
12	3.3
10	5.3
8	8.4
6	13
4	21

Tab 1.3 Conversion from AWG to mm²

1.9 EXTERNAL FUSES



CAUTION : Equipment suitable for use on a supply capable of delivering not more than 5000RMS Symmetrical Amperes ,460V +10% maximum.

No fuses are provided inside the drive. It is recommended to use UL certified fuses and fuse blocks as manufactured by BUSSMAN Div. Cooper LTD (UK).

	MicroDS Model		Notes
	□ A size		
	3/11	6/22	
Short Circuit Rating	5000 rms Amps		
Power line fuse	32A, 550 Volt, Type HRC		
Recovery Resistor fuse ³	1000V _{DC} , 3A		Semiconductor Ferraz Shawmut , A120X range.
24 Vdc auxiliary power supply fuse	3A 250V		Delayed

Tab 1.4 Recommended fuses

1.10 POWER DISSIPATION

To determine the thermal requirements of the cabinet, in which the drive is to be installed, it is necessary to refer to Tab 1.5. The power dissipation referred to in the table assumes the drive is operating at continuous rated current.

If the application employs continuous braking, it is necessary to add the recovery resistor power dissipation (use the nominal recovery power if that required by the application is unknown).

	MicroDS Model	
	3/11	6/22
Power	53W	98.8W

Tab 1.5 Power dissipation

³ The fuse specified is for operation with a nominal DC bus of 600V. For operation at lower DC bus voltages (300V), a lower voltage and current fuse can be specified.

1.11 SOFT START

The soft start circuit (current limit at start-up) is included in the drive-input stage.

1.12 FANS

The MicroDS ventilation is provided by one fan mounted over the drive. Fan power is generated internally.



CAUTION: *Free air circulation must be ensured for correct fan operation.*

1.13 RESET BUTTON

A reset button is available on the drive front panel. It allows the digital control card to be reset. It can also be used during start-up to access the download data mode.

1.14 POWER LINKS AND CONNECTORS

Remark: Moog MicroDS drives include all necessary connectors for correct operation.

All the drives are equipped with plug-in connectors to ensure quick and easy connection of the drive in the control cabinet. These connectors also facilitate service and repair activities.

The MicroDS connectors allow for easy mounting of the drive inside the control cabinet, providing the customers with the option of separating the cabinet assembly from system completion with servo-systems.

The following sections detail the connectors and their specifications for each function of the drive and their associated accessories.

1.14.1 Power input voltage connectors

□ **A SIZE:** Power supply, recovery resistance, motor output connections and 24V supply are grouped together on connector J6, on the drive's lower side. The conductors are fastened by means of screw terminals.

- Fixed connector: 12 pins, male connector
- Mating connector, 12 pins, female, supplied with the drive
- □ A size wiring: cable 14AWG (2.1 mm²). Wire stripping: 7 mm.
- Tightening torque: 0.5Nm.

Pos.	Name	Function
1	DC-	DC Bus Voltage minus connection
2	DC+	External recovery resistance and DC Plus of DC Bus plus connection
3	RR	External recovery resistance
4	L1	Phase "L1", three-phase voltage input 230/460Vac ±10%
5	L2	Phase "L2", ", three-phase voltage input 230/460Vac ±10%
6	L3	Phase "L3", ", three-phase voltage input 230/460Vac ±10%
7	PE	Protective Earth
8	W	Phase "W", motor three-phase output
9	V	Phase "V", motor three-phase output
10	U	Phase "U", motor three-phase output
11	+24V	Auxiliary voltage inputs 24 Vdc ±10%, 1A
12	GND (24V)	Auxiliary voltage inputs return

Tab 1.6 J6 Power connector, A Size

Remark: Pins 11 and 12 are the 24-Volt auxiliary voltage inputs. Pin 12 is connected to drive logic 0 and PE.

- Use a 6 AWG or 10 mm² cable and lug for M5 PE stud.

Pos.	Name	Function
PE	PE	Equipotential protection circuit.

Tab 1.7 PE Screw, □A

Remark: In electrically noisy environments, it can be useful to connect the motor ground to the PE stud and pin 7 of J6 connector to PE.

1.14.1.1 24V Auxiliary voltage




Fig 1.4 24V Auxiliary Supply Connection to MicroDS

The Auxiliary supply for the MicroDS is connected to pins 11 and 12 of J6.



NOTE: To comply with the EMC Directive an external filter (Schaffner Fairrite ferrite clamp, p/n # 00443164151) is required. Four turns of the 24V supply cable are required to pass through the clamp for compliance. Upto four MicroDS units can be connected to one filter.

1.14.1.2 Motor power connector

The motor phase connections are made on J6 as detailed in Tab 1.6. The motor phase cable must be shielded to comply with the EMC Directive. The connections are shown in Fig 1.5. See also Section 2 Installation.




Fig 1.5 Motor phases wiring



CAUTION: *U-V-W sequence at the drive side must match the corresponding U-V-W sequence at the motor side.*



NOTE: *To comply with the EMC Directive the motor cable must be shielded and the shield must be connected to the housing with a 360 ° connection at both ends.*

SECTION 1 : DESCRIPTION

1.14.1.3 Mains Voltage Supply

The mains supply voltage is connected to pins 4, 5 and 6 of J6. These lines do not require shielding. For EMC compliance, they must be connected to the input EMC filter. The input PE connection should be tied to the PE stud detailed in Tab 1.7.



NOTE: To comply with the EMC Directive, an input EMC filter is always required. Details of the recommended filters are given in Section 2, Installation.




Fig 1.6 AC Mains Wiring

1.14.1.3.1 SINGLE PHASE OPERATION

The MicroDS can operate from a single phase 230V supply. This will result in a DC bus of 320V. However, it is necessary to power limit the application to an input power of 1.1kW. Increasing the power beyond this point will result in the drive reporting an undervoltage due to excessive voltage ripple on the DC bus. To avoid this, the MicroDS should, where possible, always be connected to a three phase supply. If the MicroDS is connected to a single phase supply, an EMC filter must be installed. This is detailed in Section 2.

1.14.1.4 PARALLEL DC BUS OPERATION

The DC bus is available on pins 1 and 2 of J6. Up to four MicroDS units can operate with their DC bus connections shared. This feature allows the MicroDS units to share recovered motor power. It also increases the effective recovery energy that the drives can dissipate, as all recovery resistors will operate in parallel.

Care should be taken when paralleling the MicroDS units to ensure that the DC bus cables are kept as short as possible. See Section 2, Installation. The ratings of the DC link current is detailed in Section 6.



NOTE: To comply with the EMC Directive the DC Bus cable must be shielded and the shield must be connected to the housing with a 360° connection at both ends.




Fig 1.7 DC Bus sharing Wiring

1.15 Recovery circuit

Under braking conditions, the motor will return energy that cannot be sent to the line, as the rectifier circuit, formed by a diode bridge, is unidirectional. The regenerated energy will increase the DC-BUS voltage. When DC bus voltage reaches the intervention threshold, the digital control turns on the recovery power switch, thus connecting the recovery resistance across the DC bus and dissipating the motor braking energy as heat.

The correct sizing of the recovery resistance allows motor deceleration within the required times and protects the electrolytic capacitors and drive from overvoltage.

The MicroDS is equipped with an internal recovery resistor. This resistor is protected in software to prevent the power dissipated exceeding the device ratings (Size:3 50W, 6.25A, Size 6 100W, 6.25A). The regeneration terminals are also available on J6, pins 2 and 3. An equivalent resistor can be connected externally to double the recovery power handling capability of the unit. The software model controlling the recovery resistor operation allows increased dynamic braking capability at the start of a dynamic braking cycle. This is achieved by modeling the thermal response of the recovery resistor. This allows the recovery circuit to turn on initially for a longer period of time thereby increasing the time for which peak power can be dissipated. The software limits the overall power dissipated to the ratings of the resistor.




Fig 1.8 Recovery Resistor Wiring

If the recommended Moog external recovery resistor is used (C25722-003-121), it must be provided with suitable heatsinking. To achieve the rated power of the resistor, a heatsink of 400mm x 400mm x 3mm is required.



WARNING: *High Voltage. The recovery resistance is connected to the DC-BUS which can reach a voltage of 790V.*



WARNING: Do not touch recovery resistors during operation to avoid burns due to the heat it dissipates.



CAUTION: In applications where the working cycle involves decelerations with high inertial loads, from high velocity in very short deceleration time, it is necessary to properly size the recovery resistance. In these cases, please contact Moog Service Centers.



NOTE: To comply with the EMC Directive the recovery resistance cable must be shielded and the shield must be connected to the housing with a 360° connection at both ends.

1.16 CONTROL CARD LINKS AND CONNECTORS

The following connectors are common to all drives sizes and are all located on the drive front control card:

- Encoder Input Connector,
- Resolver Connector,
- Reference Connector,
- Drive Enable Connector,
- Encoder Output Connector
- RS485 Connector.

These are detailed in the following sections. Sufficient depth must be allowed in the cabinet for the resolver and RS485 connectors and their associated cable bend radii.

The recommended depth for these is shown in Fig 1.9.




Fig 1.9 Resolver \ RS485 Bend Radius Requirements

1.16.1 Encoder input connector

Remark: Two sections form the motor control encoder.

- The first, (UVW signals), generates signals used by the drive to power the motor phases. The number of motor poles defines this section.
- The second, (ABC signals), generates reference signals, which are also available for motion control to an external CNC. The number of pulses in this section is defined according to the customer needs as well as the application requirements.
- The connector for these signals is on the control card bottom side.
- The floating encoder connector at the drive side is a Sub-D 15 pos. and is provided with the drive (Sub-D 15 pos. Code AK5221, conductive shell, Code AK4218).
- All the motor encoder channels and the PTC/NTC for the motor temperature control must be connected to J4 connector located on the bottom side of the drive.
- Incremental encoder signals are available as outputs on J2C connector.
- For the encoder signals, It is recommended to use a low capacitance, shielded (with 85% min. coverage), multipolar cable with 22 AWG (0,30 mm²) or 20 AWG (0,50 mm²) conductors.
- Cable length should not exceed 40 m.
- It is recommended that the encoder and the motor power cable be separated, through the use of independent duct, by a distance of 30 cm (1').
- It is not recommended to make intermediate connections on the encoder cable.
- Motor Encoder port for the Motor Encoder Channels and for the Motor Integral NTC/PTC Temperature Control (PIN 8-15). This Auxiliary-connector is referred to Limited Voltage / Current circuits (rated max 5.5 Vdc \pm 10%, 400 μ A).

SECTION 1 : DESCRIPTION

Fixed connector (Motor Side): female, Code AK4220

Pos.	name	
1	+5V	+5 Vdc (max 100 mA) output
2	GND (PTC)	Encoder ground and motor PTC/NTC ground
3	\overline{W}	Switching signal: W phase (compliment)
4	W	Switching signal: W phase
5	V	Switching signal: V phase
6	\overline{V}	Switching signal: V phase (compliment)
7	A	A Channel
8	\overline{A}	A Channel (compliment)
9	C	Marker
10	\overline{C}	Marker (compliment)
11	U	Switching signal: U phase
12	\overline{U}	Switching signal: U phase (compliment)
13	\overline{B}	B Channel (compliment)
14	B	B Channel
15	PTC	Motor PTC/NTC

Note: Signals A,B and C are available on the connector J2C (Encoder Output) after a “buffer” circuit which is provided to protect encoder devices from incorrect wiring.

Tab 1.8 J4 Connector – Sub-D 15 pos. – Encoder inputs





Fig 1.10 – ENCODER CONNECTIONS

Standard / Standard



- Connettore/Connector
- PT 00E 14-19 PC10
- L Fase/Phase U
- E Fase/Phase V
- D Fase/Phase W
- J Fase/Phase C
- P Fase/Phase B
- G Fase/Phase A
- A +5V
- M Fase/Phase \bar{U}
- F Fase/Phase \bar{V}
- C Fase/Phase \bar{W}
- K Fase/Phase \bar{C}
- N Fase/Phase \bar{B}
- H Fase/Phase \bar{A}
- R PTC
- B Terra/Ground
- V PTC Terra/Ground

Fig 1.11 Encoder connection at motor side for FAEN

1.16.2 Resolver input connector

The connector for these signals is J5. J5 is a female Sub-D 9 pos. and is located on the control card.

- The resolver floating connector is a male Sub-D 9 pos. and is provided with the drive.
- Depending on the resolver transform ratio, (0.5 for Global/FASG motors, 0.25 for FAS motors), a gain setting for the resolver circuit must be set internally during manufacture. The ordering information for this is included in the BoxCar.
- The resolver signals should be connected to J5 connector. Fig 1.12 shows the resolver wiring lay-out with differential inputs.
- It is recommended to use low capacitance, multipolar shielded cable (85% min. coverage) with 22 AWG (0,30 mm²) or 20 AWG (0,50 mm²) conductors (Order code: Bare cable B47885-001).
- Cable length should not exceed 30 m. It is recommended that the resolver cable and the motor power cable be separated through the use of independent ducts and by a distance of 30 cm (1'). It is not recommended to make intermediate connections on the resolver cable.
- With the resolver interface it is possible to provide simulated encoder outputs on J2C. The maximum number of pulses per mechanical revolution of the simulated encoder is $1024 * \text{resolver poles} / 2$ (i.e.: for a 6 pole resolver, the number of pulses/revs is 3072) and the standard width of the marker is 90° (width of 180° or 360° is programmable via keypad). A lower number of pulses per revolution is programmable via keypad or through the Moog GUI.
- Ready made cables for FAS and G400/G330 motors are available on request. Contact Moog sales for further information.
- Motor Resolver port for the Motor Resolver Signals and for the Motor Integral NTC/PTC Temperature Control (PIN 6-8). This Auxiliary-connector is referred to Limited Voltage / Current circuits (rated max 5.5 Vdc \pm 10%, 400 μ A).




Fig 1.12 - RESOLVER CONNECTIONS (FAST/FASK motors)

Fixed connector: 9 pin, female, code AK4220

Floating connector: male, Sub-D 9 pos., code AK5220, provided with the drive.

Pos.	Name	
1	Cos	Differential cos signal non-inverted input amplifier from resolver windings.
2	$\overline{\text{Cos}}$	Differential cos signal inverted input amplifier from resolver windings.
3	Shield	Shield (internally connected to 0V)
4	Sin	Differential sin signal non-inverted input amplifier from resolver windings.
5	$\overline{\text{Sin}}$	Differential sin signal inverted input amplifier from resolver windings.
6	PTC	Motor PTC/NTC input
7	$\overline{\text{V ref}}$	10 kHz, 20V _{pk-pk} sinusoidal “negative” output signal to primary resolver winding.
8	PTC	Motor PTC/NTC input
9	V ref	10 kHz, 20V _{pk-pk} sinusoidal output signal to primary resolver winding (carrier).

Tab 1.9 - J5 Connector- Sub-D 9 pos.- FAST/FASK Resolver

MOTOR RESOLVER CONNECTOR (FAST and FASK)		
Signal type	FAS T/ FAS K	FAS N/ FAEN
	Pos.	Pos.
Cosφ	C	1
$\overline{\text{Cos } \varphi}$	E	2
V-Ref	D	10
0V	B	7
PTC	N	8
PTC	A	9
Sinφ	G	11
$\overline{\text{Sin } \varphi}$	H	12
shield	S	3

Tab 1.10 Resolver connections to motor

Connettore segnali / *Signal connector*
PT 00E 14-19 PC-10, PT06F 8AG 14-19S





Fig 1.13 Resolver connection at motor side for FAST and FASK

READY MADE MOTOR RESOLVER CABLES (FAST and FASK)	
Cable Part No:	Length (m)
L081-136-A001	3
L081-136-A002	5
L081-136-A003	10
L081-136-A004	15
L081-136-A005	20

Tab 1.11 Ready Made Resolver Cables (FAST & FASK)

Segnale - Signal

Standard / Standard



(FAS N)

Connettore/Connector

IPS02A 12-12PYC/SH

1 $\cos \varphi$ 2 $\overline{\cos \varphi}$

3 Schermo/Shield

7 0 V

8-9 PTC

10 V-ref

11 $\sin \varphi$ 12 $\overline{\sin \varphi}$

Fig 1.14 Resolver connection at motor side for FASN and FASY

1.16.2.1 G400 and G330 motors resolver wiring




Fig 1.15 - RESOLVER CONNECTIONS (G400\G330 motors)

Terminal Motor side	N° Terminal Drive
1	1
2	2
	3
4	4
3	5
5	6
6	8
7	7
8	9

Tab 1.12 Cross references between color and cables for G400/G330

- Terminals are identified on the motor side.
- As G400 and G330 have an NTC for thermal feedback, it is necessary to set this in the motor menu of the MicroDS setup.
- If the drive is to be used with a global motor, the order code must be specified for a resolver transform ratio of 0.5.

SECTION 1 : DESCRIPTION

Note: As the resolver is locked mechanically in the motor, the customer must perform a PHASING using the drive utilities.

READY MADE MOTOR RESOLVER CABLES (G400\G330 Motors)	
Cable Part No:	Length (m)
L081-138-A002	5
L081-138-A003	10
L081-138-A004	15
L081-138-A005	20

Tab 1.13 Ready Made Resolver Cables (G400\G330 Motors)

1.16.3 Input References Connector


The analog references (speed and current limit references) are available on J2A male connector, and accessible through a floating 4 pin female connector. The conductors are fastened using spring clips within the connector. These clips are released by depressing the tab with a screwdriver.

- Fixed connector:- 4 pins male, MicroCombicon.
- Floating connector:-insertion type, 4 pin, code AK4714 (provided with drive).

Pos.	Name	Description
1	V Ref	Differential, non-inverted input of speed or torque reference signal (0 - $\pm 10V$, corresponding to 0 - \pm Max input reference). The scale is adjustable via software from ± 3.2 to $\pm 10V$ in steps of 0.1 V. Input impedance is 10k.
2	$\overline{\text{V Ref}}$	Differential, inverted input of speed or torque reference signal
3	I limit	Differential, non-inverted input of analog current limit (0 - $\pm 10V$, corresponding to 0 - 100% max set current). The scale is adjustable via software from ± 3.2 to $\pm 10V$ in steps of 0.1 V. Input impedance is 10k.
4	$\overline{\text{I limit}}$	Differential, inverted input of analog current limit

Tab 1.14 Speed and Torque References connection

Example for speed and torque reference wiring



Note: J2A and J2B with differential and unipolar connection options.

Fig 1.16 Example for speed and torque reference wiring

1.16.4 Drive enable connector

Drive enable, Drive OK, Tacho out, Analog out, and Reference enable are available on the male J2B connector and are accessible through a floating 12 pin connector. The conductors are fastened using spring clips within the connector. These clips are released by depressing the tab with a screwdriver.

- Fixed connector: 12 pin, male, MicroCombicon.
- Floating connector: insertion type, 12 pin, code AK4722

Pos.	Name	Description
1	+15 out	+15 V _{dc} output, max 100 mA
2	0V	Logic Zero.
3	Analog out	Configurable output (see Analog out configuration) Output impedance =100Ω
4	Tacho Out	Speed signal output (0 - ± 10V, corresponding to 0 - ± Max speed rpm). The scale is adjustable via software from ±5 to ±10 V in steps of 0.1 V. Output impedance =100Ω
5	Reset +	Opto-isolated Reset inputs (15 V _{dc} / 12 mA).
6	Reset -	Reset inputs return. The MicroDS can be reset if a pulse > 20ms is applied to the reset inputs.
7	Drive Enable +	Opto-isolated Drive Enable inputs (15 V _{dc} / 12 mA).
8	Drive Enable -	Drive enable return. Power cannot be supplied to the motor without this enable signal.
9	Ref. Enable +	Opto-isolated Ref. Enable inputs (15 V _{dc} / 12 mA).
10	Ref. Enable -	Ref. Enable return. When this signal is not applied, the command to the motor is zero. If in speed mode, the speed command is zero. If in torque mode, zero torque is commanded. This input can be used for emergency braking.
11	Drive OK +	Drive OK output. Contact closes if no faults are detected. (24V relays, max 100 mA)
12	Drive OK -	Drive OK return. <i>It is recommended to logically connect the DRIVE OK isolated output to the power contactor. This ensures that the power supply is disabled in case of a fault.</i>

Tab 1.15 Drive enable connection




Fig 1.17 INPUT/OUTPUT WIRING

1.16.5 Encoder Connector (output)

The drive encoder signals are available on the 6 pin J2C connector and are accessible through a 6 pin floating connector (code Moog AK4716). The conductors are fastened using spring clips within the connector. These clips are released by depressing the tab with a screwdriver.

- Fixed connector: 6 pin, male, MicroCombicon.
- Floating connector: 6 pin, code AK4716

Pos.	Name	Description
1	A	Encoder output: A channel
2	\bar{A}	Encoder output: A channel negative
3	B	Encoder output: B channel
4	\bar{B}	Encoder output: B channel negative
5	C	Encoder output: marker
6	\bar{C}	Encoder output: marker negative

Tab 1.16 Encoder output connections

1.16.6 RS485 Serial link

RS485 serial interface signals are available on the Sub-D 9 pos., J1 connector. The corresponding floating connector is a female 9 pin connector (code Moog AK5220).

Up to 62 drives can be connected through the RS 485 serial link.

Fixed connector: male 9 pin, Sub-D

Floating connector: female, Sub-D 9 pos., code AK5220

Pos.	Name	
1	+RX	+ Rx (RS485)
2		N.C. (Not Connected)
3	+TX	+ Tx (RS485)
4		N.C.
5		N.C.
6	-RX	- Rx (RS485)
7	0V	Digital 0V
8	-TX	- Tx (RS485)
9		N.C.

Tab 1.17 J1 connector – Sub-D 9 pos. – RS485 serial link

1.17 Drive Starting Sequence.

In order to correctly power and enable the MicroDS, it is necessary to follow a start-up sequence. The minimum delay times in order to allow the internal circuits to reach the operating voltage levels and to make the internal devices ready for enabling are indicated. The chart below summarizes the start-up sequence and details the sources of the delays.

t1: Time delay required for the following operations:

- Switching on of the 24V power supplier and input voltages stabilization
- Program loading and logic circuits initialization
- Internal protections check carried out by the internal microprocessor

t2: Reset pulse to allow the reading of reference voltages, as well as the internal offsets initialization.


t3 Time needed by the drive to boot up after the reset.

t4 Charge time of Bus capacitors determined by the soft-start circuit and Bus voltage stabilization.

t5 Time for DRIVE OK acquisition by the control

t6 Time to allow the Drive to reach the torque and to check the proper operation of power stages.

The times indicated in the following table are necessary to avoid FAULT occurring on startup.



$t_1 \geq 3 \text{ s}$, $t_2 \geq 100 \text{ ms}$., $t_3 \geq 1 \text{ s}$, $t_4 = 3 \text{ s}$, $t_5 \geq 100 \text{ ms}$., $t_6 \geq 100 \text{ ms}$.

Fig 1.18 – STARTING SEQUENCE TIMES

Remarks:

- The reset pulse re-initializes the card with all internal voltages stabilized. This allows a more accurate determination of voltages for compensation of internal offsets.
- The RESET is necessary only on the first drive start-up or, in the case of a FAULT, to reset the drive.
- The DRIVE OK signal requires the line voltage be applied before becoming active. Once DRIVE OK is active, the drive can be enabled immediately.

1.18 Dynamic Braking

It is possible to perform dynamic braking of a load using the motor torque, in an emergency condition, provided that the drive or motor is not in a FAULT condition.


To achieve this, the drive command sequence detailed below should be followed.

When dynamic braking of the motor is required, the REFERENCE ENABLE is removed and the motor will brake with the available torque.

t1: after 100ms (this time can be increased in cases where load inertia is much larger than motor inertia) the DRIVE ENABLE can be removed.

t2: The three-phase input voltage removal is delayed with respect to DRIVE ENABLE in order to avoid drive FAULTS due to an undervoltage condition being detected.

t3: DC BUS discharge time



$t_1 = 100\text{m s}$, $t_2 = 15\text{ ms}$, $t_3 = 6\text{ min}$. (before accessing the drive).

Fig 1.19 – SWITCH-OFF SEQUENCE TIMES

1.19 MECHANICAL BRAKING

The FAST ACT series motors have an optional electromagnetic brake. This brake requires an external supply of 24V. This brake can be used to hold the motor



CAUTION: *The brake must be used only when the motor has come to a standstill. The use of this brake for dynamic braking will seriously damage the brake and reduce the braking torque.*

Note: T1 ≥ 300 ms, T2 = application depending, T3 = 100 ms, T4 ≥ 200 ms




Fig 1.20 – MECHANICAL BRAKING SEQUENCE

Note:

- 1)** The time for brake ON and OFF is different for different brakes models. Please refer to the motor catalogue for updated data.
- 2)** Brake voltage should be 24 volt (-0%, +10%), measured at the motor.

SECTION 2 INSTALLATION**2.1 INTRODUCTION**

This section provides the necessary information for drive installation. Dimensions and the required connections are also detailed.

2.2 INSTALLATION REQUIREMENTS

For correct installation it is necessary to:

- Prepare a metal support on which to mount the drive. Leave at least 20mm (0.8") of space around the drive.
- Provide adequate ventilation to dissipate the heat produced by the drive and the recovery resistance if the drive is installed in a cabinet.
- Provide shielded power connection cables having an appropriate cross section for the motor.
- Provide a cable run for the resolver or encoder cables, which is separated from the power cables by at least 30cm (1') in a separate cable duct.
- Provide grounding to PE using short cables having an appropriate cross section to increase immunity from radio disturbance.
- Install recommended EMC components for electromagnetic compatibility.

Detailed information is available in the following paragraphs.




Fig 2.1 Typical Drive Installation

2.3 ELECTROMAGNETIC COMPATIBILITY

2.3.1 EUROPEAN DIRECTIVE EMC (89/336/EEC)

Compliance with the European Directive 89/336/EEC is required for all electric and electronic products brought onto the European market after December 31st, 1995.

MicroDS drives with FASTACT and Global motors meet the following EMC product standard related to the Directive:

EN 61800-3 (1996) and EN 61800-3/A11 (2000): "Adjustable speed electrical power drive systems. Part 3: EMC product standard including specific test methods". Second environment (industrial) compatibility levels.



NOTE: *To comply with the EMC Directive, the drive must be installed with the appropriate EMC filters. The installation must adhere to the recommendation given in the following sections.*



NOTE: *This equipment is not intended to be used on a low-voltage public network, which supply domestic premises. If connected to such a supply, this product may cause radio interference in which case supplementary mitigation measures may be required.*

Testing has been carried out at an independent test house to the above directive.

The drive installer is responsible for ensuring compliance with the EMC regulations that apply where the drive is to be installed. Recommended filtering, wiring, grounding and screening is detailed in this section.

2.3.2 FILTERING

2.3.2.1 Filter types

The following filters are recommended for EMC Compliance.

Code	Trade-mark	Rated current [A] A 50°C (40°C)	Max Voltage [Vac] A 50°C	Drive type / input
-	Schaffner Fairite Clamp Part # 00443164151	-	-	24 V _{dc} input
AT6009	Schaffner FN 258-7/07	7 (8.4)	3x480	MicroDS 3/11 MicroDS 6/22
-	Schaffner FN 350-12/29	13.8 (12)	1x250	MicroDS 3/11 (Single Phase Operation only)

Tab 2.1 Recommended filter types

The Fairite clamp should be placed on the 24V input lines with 4 turns wrapped in a common mode fashion (both lines wrapped in filter in same direction).

The FN258-7/07 can be used with up to four MicroDS drives. Care is necessary to ensure the power requirements of the application do not exceed the filter ratings.


2.3.2.2 Filter Sizing

In standard applications the filter can be chosen from Tab 2.1. The filters can be sized more accurately if the effective current (rms) the drive absorbed in the application is known. If this information is not available, the filter can be sized according to the motor nominal current.

2.3.2.2 FILTERS MECHANICAL DIMENSIONS

The following table details the mechanical dimensions of the suggested filters.

Code	Trade-mark	Dimensions [mm]							Weight [kg]
		L1	L2	L3	L4	L5	L6	L7	
AT6009	Schaffner FN 258-7/07	255	240	50	25	225 ±0.8	126 ±0.8	300	1.1
-	Schaffner FN350-12/29	99.5	51	105	95	99.5	57	Terminal blocks only	0.9



Tab 2.2 Filters mechanical dimensions

2.3.2.3 Filter installation

The filter must be mounted on the same panel as the drive.



CAUTION: A space of at least 60mm (2.4") must be left around the filter for air circulation when the cabinet does not have forced ventilation.

The filter must be located as close as possible to the drive input. If the separation between filter and drive exceeds 30 cm (1') , then a flat cable (multi-thread copper flat cable) should be used for the RF connection between filter and drive.



NOTE: Before mounting the drive and the filter to the cabinet, check that the panel surface is conductive. If not, remove any paint and/or other insulating material before mounting the drive and filter.

The max tightening torque of mounting screws are as follows:

FILTER	MAX TORQUE
FN 258 - 7/07	0.8 Nm
FN350 – 12/29	0.5Nm

Tab 2.3 Mounting screws torque table

EMC filter can produce high leakage currents to ground (Protective Earth). The current levels associated with individual filters are detailed in the associated filter datasheet.

Note1: *if two phases are interrupted, leakage current can reach six times the default level.*

Note2: *The capacitors within the filters have discharge resistors.*



CAUTION: *The filter must be connected to earth before connecting the supply*



WARNING: *High voltage – Internal filter capacitors discharge time: approx. 10 seconds.*

2.3.3 Wiring and shielding



The following cables must be shielded, with 85% minimum shielding coverage:

- Motor power cable (see Fig 2.2 & Fig 2.3)

NOTE: if a power terminal board is used at motor side, the shield must be RF connected to the ground screw by a metal clip

- External recovery resistor cable
- DC Bus Cable




Fig 2.2 – Grounding of shield To connectors at motor side

- Encoder cable (see Fig 2.2)
- Analog/Digital I/O cable
- RS485 cable
- Resolver cable (see Fig 2.2)

The shield of the cables must be connected at both ends with a 360° connection to a metal connector or with metal hose clamps.

For Sub-D connectors, the cable shield must be connected to the metal case of the connector.

When there is no connector at the drive, an EMC connector kit is provided.

The insulation on the shield of the cable must be stripped back and the shield RF connected to the stand-off through the hose clamp, as in Fig 2.3.




Fig 2.3 Grounding of shield to housing




Fig 2.4 Connection at Drive Side μ A Size

Note: Unshielded (three-phase power supply) and Sub-D cables are not shown in Fig 2.4



NOTE:

- The shields of cables inside the cabinet must be 360° clamped to the cabinet wall (see Fig 2.5).
 - noisy cables must be kept away from sensitive cables by at least 30 cm (1'). Noisy cables include input power wires, motor power and brake wiring. Sensitive cables include analog or digital signal cables; encoder cable; Analog/Digital I/O cable; RS485 serial link.
 - where noisy cables must cross sensitive cables the cables should cross at right angles.
- The 24V Backup supply cable should be routed as far from the motor power cables as possible to ensure EMC compliance.




Fig 2.5 Backpanel connection




Fig 2.6 Partition penetration

Penetrating cabinet partitions should be accomplished with a RF connection from the cable shield to the enclosure.

If a connector is not used, the connecting copper strap should be kept as short as possible (see Fig 2.6).

2.3.4 Recovery resistor



To meet the EMC Directive the enclosures housing the recovery resistors must be conductive. The recovery resistor cable must be shielded and the shield must be 360° clamped at both sides.



CAUTION: Before mounting the recovery resistor enclosure to the panel ensure that any paint or other insulating material is removed.

2.3.5 Shielding

To effectively shield the system, all the single shields (CNC, cabinet, machine, motor housing, cables) should be connected together to form one full shield.

2.3.6 Safety Aspects

Noise suppression of motor drive systems requires consideration of the earthing system and its effectiveness at high frequencies. Safety aspects must also be considered and must, where appropriate, take priority over EMC requirements.

To reduce the radiated emissions, the use of capacitance to earth is very effective. These capacitors conduct current from phase to earth. Depending on the filter design, this current can be in the order of hundreds of milli-amps.



WARNING: *Appropriate safety measures should be taken to ensure that this potentially dangerous current flows to earth by a low impedance connection. These filters should be connected to Earth before being energized.*



CAUTION: *It is recommended to disconnect the drive and the EMC filters before carrying out the 50Hz “AC voltage test” of CEI EN 60204-1 (Par.20.4), according to the Machinery Directive (89/392/EEC) and to the Low Voltage Directive (73/23/EEC).*

2.4 Summary of Connection Instructions

Power connections can be divided into:

- a) "Temporary connections". These are made to allow parameter setup with auxiliary power input only and/or for testing purposes.
- b) "Permanent connections". These should be made according to guidelines outlined above.

Signal and motor feedback (resolver or encoder) connections should always be made according to the guidelines given in this manual, to prevent noise affecting drive operation.

2.4.1 Feedback connection (encoder or resolver)

Feedback connection must always be made according to the specification in of Section 1 regardless of whether the drive is being set up with "Temporary" or "Permanent" supplies.

Inadequate shielding can cause feedback errors and may affect motor operation.

2.4.2 "Temporary" / test power wiring

Unlike the DS2000, the MicroDS must be supplied 24V backup power before the drive will operate and any testing can be carried out.

Remark: it is not possible to enable the output stages when the DC BUS is not powered. A DC BUS UNDERVOLTAGE FAULT will be reported.

If the drive is connected for test purposes only, an unshielded motor power cable can be used. The cross section of the cable connecting the drive to the AC line supply and to the motor can be lower than that recommended for the drive size if drive peak current will not be supplied and the connection is made for test purposes only. The motor should also be used at low speed and reduced torque.

A soft-start circuit is always present and active on each drive. The line current drawn by the drive during soft-start is limited by an internal 120Ω resistor. However, it is recommended to protect the power-input line with fuses or a circuit breaker.

2.4.3 Summary of power wiring

To correctly wire and install the drive it is necessary to limit electromagnetic disturbances between the servosystem and other electronic devices. The measures needed to ensure this are summarized in the following points.

- a) Install the EMC filter on the input line to reduce the conducted emissions on the AC mains supply.
- b) Provide connections between the filter and drive using minimum cable lengths.
- c) Use a shielded cable motor power cable.
- d) Use shielded cable for the feedback signal connection between motor and drive.
- e) Place motor power and feedback cables in separate ducts or separated by at least 30 cm (1').
- f) Use shielded cables for the analog reference cables and digital I/O cables. Separate them from the motor power cables.
- g) Use twisted pair shielded cable for the encoder connections between the drive and the controller. If termination is not provided, terminate the cable at the control side using a 220 Ω resistor.

SECTION 3 STARTUP**3.1 INTRODUCTION**

The section outlines a series of simple steps, which will allow a user to quickly and easily setup a MicroDS drive for the first time.

The information is provided in a manner that is simple and descriptive to allow it to be understood by those not familiar with servo-drive operation.

Refer to the previous sections for more detailed information on cable connections.

Refer to Section 5 for a detailed description of motor and drive parameters.

3.2 DRIVE SETTING UP INFORMATION

To set up the servo-drive and motor, the drive must be configured with the correct motor and drive parameters (unless configured by Moog at the customer's request).

The necessary parameters are detailed below:

Motor settings

- 1) Number of motor poles
- 2) Motor max current
- 3) Motor voltage rating
- 4) Motor nominal speed
- 5) Motor BEFM (at 1000 rpm)
- 6) Motor resistance
- 7) Motor inductance
- 8) ID magnetization current (for asynchronous motors only)
- 9) SG slip (for asynchronous motors only)
- 10) Resolver or Encoder feedback.
- 11) Resolver/Encoder phase. Can be determined using the Phasing function.
- 12) Number of encoder pulses / number of resolver poles
- 13) Number of pulses per electrical revolution needed by the CNC (resolver interface only)
- 14) Zero marker width (resolver interface only)

Remark: It is not possible to modify the number of output pulses and the zero marker width when operating with encoder feedback. This function is available only with resolver feedback.

Drive settings

- 15) Remote \ Local drive enable
- 16) Max. motor speed command
- 17) Max. drive current
- 18) Speed or torque control. Set to speed control when drive is used for testing.
- 19) ACC/DEC value (only in speed control mode. Function is disabled when set to 0)
- 20) Analogue \ Digital reference control
- 21) Digital (set by drive) or analog (set by control) current (torque) limit
- 22) Speed loop VKI and VKP (speed integral and speed proportional gain). Set by motor loading.
- 23) LPF filter setting on error and reference. Notch filter setting

Some of the information may be missing during installation. However, the installation can be carried out, as it is possible to enter the data subsequently using the built-in keypad or the MOOG GUI

Remark: The display indicates drive & motor status by the switching on or off the display backlight.

The backlight is lit if no FAULTS are detected (refer to Section 5).

The display is not lit if no FAULTS are detected (refer to Section 5).

3.3 First start-up (on test bench, for testing purposes)

- Connect the power supplies (24V backup and AC Mains).
- Connect the motor feedback (resolver or encoder) and motor power cable.
- Connect an analog reference to V_{ref} and enable signals (signal not active) to DRIVE ENABLE and REFERENCE ENABLE.
- Power the drive (24V backup & AC Mains) without applying DRIVE ENABLE or REFERENCE ENABLE.
- The display backlight should light if no faults are detected. If a fault is detected, check faults in the appropriate menu (See Section 5).
- Hand-rotate the motor shaft. Check the speed reading displayed in the “Display Variables” menu (See Section 5).
- To power the motor, apply DRIVE ENABLE and the REFERENCE ENABLE. The motor should rotate correctly if all connections and settings are correct.
- If the motor does not rotate correctly, refer to Section 8 (Troubleshooting).

3.4 Configuration for installation in the electrical cabinet.

Additional setting for installation, **Drive remote enable.**

- In order for the CNC to control drive enable, the Drive enable setting should be set to remote.
- All test settings used on the test bench which limit performances should be removed.

SECTION 4 OPERATION**4.1 INTRODUCTION**

This section details the operation of the MicroDS.

4.2 GENERAL PRINCIPLES

The drive and motor operate as an electro-mechanical converter transforming electrical energy, drawn from the power line, into mechanical energy.

4.2.1 Input electric power conversion

The three-phase supply voltage is converted to DC using a diode rectifier and smoothed by means of capacitors.

The capacitors charge current is limited using a soft start resistor. The operation of the softstart is controlled by software. This algorithm used is self-adapting to different supply voltages.




Fig 4.1 Input Rectifier & Softstart

4.2.2 Output electric power conversion

The DC bus is connected to a three-phase bridge comprised of six IGBTs and six diodes.

The IGBTs are controlled using a PWM (Pulse Width Modulation) waveform. This applies a pulsed voltage to the motor. The widths of the voltage pulses are controlled to generate a sinusoidal current in the motor thereby generating a smooth torque.

As the IGBTs always operate in a saturated mode, the losses in the amplifier are kept to a minimum.

The IGBTs are switched with a 10kHz switching frequency. This limits the losses in the motor that results from excessive high frequency current ripple in the windings.




Fig 4.2 Output section diagram

Each IGBT is protected from short circuit and overload. The protection is managed directly by the control card.

4.2.3 Control section

The drive measures the current angular position and maintains an angle of 90° between the magnetic field generated by currents and the field generated by the magnets on the rotor.

The motor position is determined by the feedback signals derived from the encoder or from the resolver through advance signal processing on the control card.

SECTION 4: OPERATION

From the data provided in the drive and motor parameters and the feedback from the motor, the drive adjusts the commands to the IGBT appropriately to supply the currents.

The current feedback is obtained by means of HALL sensors placed on motor phases U and V.

The position feedback is derived either from a resolver or an encoder.

Low Pass Filters (LPF) filters on the reference and on the speed error allow the servo-system (drive + motor) response be adapted to the application characteristics.

The Notch filter allows the affects of resonances in the mechanical system to be reduced or eliminated. Resonances can occur due to the limited rigidity of the motor transmission (mechanical transmissions, belts, etc.), particularly in presence of high inertia ratios between motor and load (mismatched load condition).




Fig 4.3 Servo-system block diagram

4.2.4 High Speed operation

The current control loop has two different working modes: Low speed and High speed. The transition is determined by motor voltage compared to the available output voltage on the inverter output.

At low speed, the voltage supplied by the drive is higher than that generated by the motor, and the magnetic field generated by current in quadrature with the field generated by magnets.

At high speed, the motor voltage is comparable to the voltage available from the drive. The phase between the magnetic fields is automatically changed to keep the motor voltage at a level where the voltage margin is adequate to allow optimal current adjustment.

This algorithm allows an optimal exploitation of motor characteristics, giving good low and high speed operation.

It is also possible to adjust the motor windings to give a higher torque constant. Using this, in many applications, it is possible to use a drive supplying a lower current to obtain the same peak torque output from the motor.

4.3 CONTROL LOOPS OPTIMIZATION

The control loops optimization can be carried using the built-in keypad or Moog GUI.

4.3.1 Current loop optimization

The current loop optimization is automatically carried out by entering the motor physical characteristics: Resistance, Inductance, and Back EMF (BEMF) constant.

Such data must be entered in physical units, resistance in Ohm, inductance in mH and the Back EMF in Volt/RPM.

The drive automatically adjusts the current loop gains and carries out the angular correction as a function of the motor rotation speed and the torque command.

No other customer calibration is needed.

REMARK: If the output current at high speed (max working speed) is greater than expected, it is possible to reduce it by reducing the motor inductance value (-20 %) and reducing the motor BEMF value. This may be necessary because of changes in motor reluctance with motor speed.

4.3.2 Speed loop optimization



Speed loop optimization is carried out by adjusting the VKI and VKP parameters. These parameters correspond, to the speed loop integral and proportional gains respectively. It may also be necessary to adjust the various digital filters in the speed loop to account for resonances in the system and to achieve the desired response. The optimization is best carried out using an oscilloscope.

The proportional gain acts on the measured velocity error, which is the difference between the requested velocity and the actual velocity. High proportional gain gives the system a faster response and tighter speed control, but if the gain is set too high the system may become unstable. For best velocity tracking results the proportional gain should be set as high as possible without inducing severe overshoot or oscillation.


The integral gain sets the gain for the integral term in the speed error compensation. Integral gain is used to remove any steady state speed error, caused by system imperfections or due to disturbance torques from the load. Integral gain also provides disturbance rejection or 'stiffness' in the motor's reaction to an external torque load. The following describes how to adjust these parameters to achieve an optimum performance.

- The proportional term is the first term to be adjusted. The integral gain is effectively turned off by setting it to zero.

- The Servo-drive should be enabled. Increase the gain until the shaft is turning. While monitoring the speed response on an oscilloscope, increase the gain until a slight overshoot occurs in the speed response (Fig 4.4 below). Decrease the gain until the overshoot just disappears (Fig 4.5 below) .

**Fig 4.4 Speed Loop Response, proportional gain only, slight overshoot****Fig 4.5 Speed Loop Response, proportional gain only, no overshoot**

- Increase the integral gain until a slight overshoot occurs.
- Adjust the proportional gain to improve the slope of the step response. Fig 4.6 illustrates the velocity wave form for a properly tuned loop.

**Fig 4.6 Speed Loop Response, correct response**

SECTION 5 COMMANDS**5.1 DESCRIPTION**

The six keys on the drive front panel allow all menus as well as the relevant drive configuration to be displayed. An additional key allows display contrast adjustment.

- **ENTER.** This key allows the user to enter a menu and browse it. The variables scanning inside a menu is recursive. In some cases, this key activates a routine function (i.e. inside the “Utility” menu).
- **< >.** These keys allow the user to move horizontally in the menu structure scrolling from right to left and viceversa.
- **+ -.** These keys allow the user to increase and decrease a variable. Holding the key down for approx. 5 s increases the increments in which the variable is changing.
- **ESC.** This key allows the user to go backwards inside the menu or terminate a function.
- **○ .** By holding down the yellow key, it is possible to adjust the display contrast by means of the + / - keys. To keep the setting, it is necessary to save the parameters before switching off the drive.

Notes:

Note 1: At start-up, the drive is in “locked keypad” status. This prevents accidental modifications to parameters and system settings. To modify parameters it is necessary to unlock the keypad.

To unlock the keypad it is necessary to activate the function “unlocked keypad” inside the “Keypad lock” menu.

Note 2: In order to save the modified parameters the function “Save Parameters” inside the “Utility menu” should be used. The save will only occur if the drive is not enabled.

Note 3: If a FAULT occurs, the display backlight will be switched off.

Note 4: The DRIVE ENABLE and REFERENCE ENABLE signals are shown in the start-up screen on the display by the characters: “D” and “R” respectively.

Note 5: The motor menu is not “circular”; when the bottom is reached, press **ESC** or < to go back.

The **Enter** button can be used to go forward in the menu.




Fig 5.1 Drive front panel

5.2 MOTOR PARAMETERS MENU

First screen at drive start-up

The first menu level can be accessed by pressing ENTER.

The first level of menu shows the two <> arrows which indicate the possibility of scrolling the menus from right to left. To access the menu, press ENTER.

When the parameter to be modified is reached, press + / - to increase or decrease the variables.

To go to the following parameter, Press ENTER or < and > keys. To exit the menu, press ESC.

Keep on pressing if the displayed parameter is not the first item of the menu.

In order to save the modified parameters, see "Save Parameters" in the "Utility" menu.

NOTES


1. The motor "size" corresponds to the motor peak current. It is generally limited by the drive size (peak current) The formula used to obtain the motor Size from Tm and Kt parameters, as indicated on the motors catalogues, is as follows:

$$I_{peak} = 1.41 * T_m / K_t$$

2: The formula to obtain the "E1000" (EMF at 1000 rpm) from Kt (RMS torque constant) is as follows:

$$E_{1000} = K_t * 60.4$$

3. In the "encoder" motor parameters the number of pulses per revolution should be set



5.2.1 DESCRIPTION OF MOTOR PARAMETERS

Poles =	Description: Indicates the motor poles number
The following values can be set. 2 to 24 in 2 units steps.	Note: for Moog motors, the following values are valid FAST, FASN = 6 poles FASK /Global = 8 poles FC /Global = 12 poles
Size =	Description: Indicates the motor peak current value.
The following values can be set. 1.0 A to the peak current supplied by the drive in 100 mA steps.	Note: If this value is not available, it is possible to obtain the peak current by means of the following formula: $I_{peak} = 1.41 * T_m / K_t$, where T_m represents the max torque, in Nm, the motor can supply, and K_t , in Nm/A _{rms} , is the torque constant.
Voltage =	Description: Indicates the motor winding voltage rating value
The following values can be set. 230 V (for motors powered by 230V drives) and 400 V (for motors powered by 400/460V drives).	Note: for Moog motors, please refer to the table below: M and K Motors = 230 V power supply V Motors = 400 V power supply
Speed =	Description: Indicates the nominal motor speed.
The following values can be set. 100 rpm to 9999 rpm in steps of 10 rpm	Note: Set the value on the motor nameplate. The max speed the drive can set is lower than or equal to this value.
BEMF =	Description: Indicates the motor back EMF voltage per 1000rpm
The following values can be set. 0 to 750 V, in steps of 1 V.	Note: The drive uses this information to optimize the current loop as a function of the motor rotation velocity. If this information is not available it is possible to obtain it by means of the following formula: $BEMF = K_t * 60.4$, where K_t , in Nm/A _{rms} , is the motor torque constant.

RW =	Description: Indicates the motor resistance value, measured from phase to phase.
The following values can be set. 0 to 30 Ohm in steps of 0.1 Ohm	Note: Set the resistance value as indicated in the motor catalogue. If it is not available, the value can be measured by means of a multimeter (used as an Ohmmeter).
Lw =	Description: Indicates the motor inductance value, measured from phase to phase.
The following values can be set. 0 to 200 mH in steps of 100 uH.	Note: Set the inductance value as indicated in the motor catalogue. If it is not available, the value can be measured by means of a multimeter (used as an inductance meter)
APHAPOS =	Description: Indicates the phase correction value between the position feedback device (resolver or encoder) and the motor phases.
The following values can be set. 0 to +/- 255 units	Note: This parameter can be automatically modified by the PHASING procedure (as described in 5.7.3). For Global motors, the phasing function must be performed on first startup.
ID =	Description: Indicates the magnetization current value for an asynchronous motor in vector control mode.
The following values can be set. 0 to the max peak current supplied by the drive in steps of 100 mA.	Note: Set magnetization current value as indicated in the motor catalogue.
SG =	Description: Indicates the slip frequency (gain) value for asynchronous motor control operating in vector control mode.
The following values can be set. 0 to 100, in steps of 0.1.	Note: Set the value as indicated in the motor catalogue. If it is not available, it is possible to measure the optimal value by analyzing the response to transients.
PTC/NTC Sel.	Description: Indicates that the motor thermal feedback is obtained by means of a PTC (FASN, FAST, FASK, etc) or by means of an NTC (Global). The NTC or PTC can be selected using the + & - keys.
INI PHASE SHIFT =	Description: Indicates the shaft speed where additional phase shift is added to the current command
The following values can be set. 100RPM to 9999RPM in steps of 10RPM.	Note: The phase shift compensates for the phase lag in the current loop response at high motor speed. Below this speed, the phase shift is zero. Above it, the phase shift increases linearly with the speed.

MAX PHASE SHIFT =	Description: Indicates the phase shift at Motor Max. Speed
The following values can be set. 0 to 100 DEG in steps of 1 DEG.	Note: This parameter operates in association with the INI PHASE SHIFT parameter to set the rate of change of phase shift.
Encoder	Description: Indicates that the motor feedback is obtained by means of a digital encoder.
Resolver	Description: Indicates that the motor feedback is obtained by means of an analog resolver.

5.2.1.1 Description of Resolver parameters

Poles =	Description: Indicates the number of resolver poles
Allowed values: from 2 to 24 in steps of two. The parameter can be varied using the + and - keys	Note: For Moog Motors, it possible to set the following values FAST, FASN = 6 poles or 2 poles FASK = 8 poles, 4 poles or 2 poles FC = 12 poles, 6 poles or 2 poles Global = 2 poles

Encoder Out Pulses=	Description: Indicates the number of encoder output pulses.
Allowed values: from 64 to 1024 pulses per resolver pole pairs, in steps of 2^n ($n=6...10$). The value can be varied using the < and > keys.	Note: The drive generates output pulses by dividing the input pulses used for motor control. For resolvers with greater than 2 poles, the encoder output count per mechanical rev. will be no of pole pairs x Encoder Out Pulses

Zero Length =	Description: Indicates the marker width.
Allowed values: 90°, 180° and 360°; The value can be varied using the < and > keys.	Note: The drive generates the pulses by dividing the pulses used for motor control.

5.2.1.2 Description of Encoder Parameter

Encoder =	Description: Indicates the number of encoder pulses from the motor feedback.
Allowed values: from 1024, to 8192 in steps of 512 pulses. The value can be varied using the < and > keys.	Note: For Moog Motors the following values are valid: 1024, 2048, and 4096 pulses per mechanical revolution.

SECTION 5: COMMANDS


5.3 DRIVE PARAMETERS MENU


Motor Parameters < Drive Parameters > Control loop parameters

The first menu level can be accessed by pressing ENTER. The first level shows the two <> arrows which indicate the possibility of scrolling the menu from right to left. To access the menu, press ENTER. When the parameter to be Modified is reached, press + / - to increase or decrease the variables. To go to the following parameter, press ENTER. The parameter scanning is recursive. To exit the menu, press ESC. Keep on pressing ESC if the displayed parameter is not the first item of the menu. In order to save the modified parameters, see "Save Parameters" in the "Utility" menu.

Notes:

- 1: The address for serial communication, from 0 to 62 (default = 1), should be set in "drive address".
- 2: "PTC intervention = 1000 Ohm"
"NTC intervention = 6500 Ohms"
- 3: It is possible to limit the current at a value lower than the drive size by setting it to a lower value in "max current".





5.3.1 DESCRIPTION OF DRIVE PARAMETERS

Drive Address Drvaddr =	Description: Indicates the drive address for serial communication.
The following values can be set. 1 to 62	Note: Set a different value for each drive. This will ensure that only one serial cable is required to communicate with all drive on a machine.
PTCNTC Threshold	Description: Indicates the PTC or NTC threshold value used to protect motor from overtemperature. If the resistor transitions over this threshold, an overtemperature fault is triggered.
The following values can be set. 100 to 10000 Ω in steps of 10Ω.	Note: Set to 1000 Ω for standard Moog PTC (FAS motors) Set to 6500 Ω for standard Moog NTC (Global motors).
Anal. Ref. Zero Band = ±	Description: Indicates the dead band on the analog inputs in which these inputs are ignored.
The following values can be set. ± 0 to ± 128	Note: This feature allows to user to set a deadband around the analog inputs. Allows minor offsets in the input to be disregarded.

<p>Recovery resist. ResRec =</p>	<p>Description: Indicates the recovery resistance value</p>
<p>The following values can be set. 60Ω to 120Ω in steps of 1Ω</p>	<p>Note: The internal recovery resistance of the MicroDS is 120Ω. This is the default setting. If an external recovery resistance is connected, it should be the same resistance and power rating as the internal device. The parallel resistance value should be entered when an external resistor is employed e.g. 60Ω if an external resistor of 120Ω is connected.</p>
<p>RR Rated Power [W]</p>	<p>Description: Sets the rated power of the combined internal and external recovery resistors.</p>
<p>The following values can be set: 0W to 200W for 6/22A μDS and 0W to 100W for 3/11A μDS.</p>	<p>Note: Using the Recovery resistor power, resistance and motor voltage parameters, the drive will calculate the maximum allowed regeneration duty cycle. This duty cycle and actual recovery resistor power are displayed in the Display Variable Menu under 'MaxRRDuty' and 'R Regen Power' parameters respectively. The recovery resistor will operate with an on-time of 200μS and variable off-time. For high dynamic braking conditions, the recovery resistor control allows an initial on-time which exceeds the 200μS.</p>
<p>Tacho Scale</p>	<p>Description: Indicates the Tacho signal value obtained at max speed.</p>
<p>The following values can be set. ±5 to ±10V in steps of 100 mV</p>	<p>Note: setting 10 Volts for the max speed value gives a simple and direct ratio between Tacho output and actual speed.</p>

<p>IT Peak IP = [A]</p>	<p>Description: Indicates the peak RMS current that the drive is allowed to supply.</p>
<p>The following values can be set: 0A to 15.6A for 6/22A μDS and 0A to 7.8A for 3/11A μDS.</p>	<p>Note: Clamped at minimum of (Motor Parameters :- Size)/√2 and (Drive Parameters:- Max Current)/√2.</p>
<p>IT Cont IC = [A]</p>	<p>Description: Indicates the continuous RMS current that the drive is allowed to supply.</p>
<p>The following values can be set: 0A to 6A for 6/22A μDS and 0A to 3A for 3/11A μDS.</p>	
<p>IT Time IT =</p>	<p>Description: Indicates the time (in seconds) for which the drive will deliver peak RMS current.</p>
<p>The following values can be set: 0 to 10 seconds in steps of 0.1sec.</p>	<p>The three IT parameters operate together to provide IT limiting on the μDS. This limits the time for which the drive will deliver peak current thereby protecting the drive connectors and internal tracking. The algorithm allows IT Peak current to flow for the specified IT Time. The algorithm operates using a simple integrator that winds up if the demanded current increases above the IT Cont. level. The IT integrator winds up according to</p> $(I_{Drive\ PK} - \sqrt{2}I_{Cont\ RMS}) \cdot time .$ <p>Once the integrator exceeds</p> $\sqrt{2} (I_{PK\ RMS} - I_{Cont\ RMS}) IT_{Time} ,$ <p>the output current is clamped to the IT Cont. level. Peak current will not be allowed to flow again until the IT integrator resets completely. The integrator unwinds according to:</p> $\frac{\sqrt{2} (I_{PK\ RMS} - I_{Cont\ RMS}) IT_{Time}}{\sqrt{2} I_{Cont\ RMS} - I_{Drive\ Pk}} .$ <p>Thus, with the following settings, IT Peak = 15.6A, IT Cont = 6A & IT Time = 10sec,</p> <p>The drive will allow peak RMS current to flow for 10 seconds. If after the 10 seconds, the command is reduced to zero, peak current will be available again after 16.0sec.</p>

Torque Improv.	Description: Allows the drive to set, cycle by cycle, the optimum angle between the output current vector and the magnet position in order to increase the peak torque at high speeds.
The following values can be set Enabled or Disabled.	Note: It is possible to set Torque Improv to enabled as the default setting. It is recommended to leave this function enabled to ensure that at higher speeds, lower motor temperatures and higher torque is achieved.
Notch Frequency	Description: Allows a programmable Notch filter to be inserted in the speed loop. This filter acts on the compensated error from the speed loop.
The following values can be set: 50 to 1500 Hz	Note: Sets the filter center frequency in Hz.
Notch Bandwidth	Description: Sets the Notch filter bandwidth.
The following values can be set: 1 to 25 Hz	Note: Sets directly in Hz the filter bandwidth.
Notch Gain	Description: Sets the Notch filter attenuation
The following values can be set: 0.1 to 1.00	Note: Allows entry, in percent, the Notch filter signal width (1.00 = 100%)
Drive enable	Description: Allows the drive to be enabled (torque supplied to motor) using the keypad or using the Enable digital input.
The following values can be set: local or remote.	Note: The default setting is local enable. The drive enable input must be active for local enable to operate. Setting Drive enable to remote enable allows the drive to be enabled on a positive transition of the Drive Enable input.
Rotation Direction	Description: Allows the motor rotation direction to be reversed for the same applied reference signal.
The following values can be set: CW (Clockwise) or CCW (Counter Clockwise).	Note: The default setting is CW (a clockwise motor rotation, when view looking in at the shaft, is obtained with a positive reference signal).
Max speed	Description: It allows the user to limit the motor max rotation speed at a lower value than that set in the motor parameters.
The following values can be set: 100 rpm to motor max speed, in steps of 1 rpm.	Note: The input analog reference scales to the Max speed setting. 10V will be mapped to Max speed.
Max current	Description: Allows the user to limit the max supplied current to a lower value than that set in the


	motor parameters.
The following values can be set: 0 to max current in steps of 100 mA	Note: The input analog reference scales to the Max current setting. 10V will be mapped to Max current.
Control types	Description: Allows the user to set the motor to torque control or speed control.
The following values can be set: Torque or Speed	Note: In speed mode, the drive regulates motor speed. The load on the motor shaft governs the applied torque. In torque control mode the set torque is supplied. Motor speed is dependent on the motor load. If the max speed is exceeded (in torque control mode) by more than 12%, a motor over-speed fault is reported and the drive disables.
Acceleration	Description: Allows the user to limit the motor maximum acceleration. This function is available in speed control mode only.
The following values can be set: from 0 to 99990 rpm/s in steps of 10.	Note: The function is disabled when set to 0. This feature can be used to prevent excessive acceleration steps being applied to sensitive loads. It allows for smooth acceleration of loads and helps eliminate overshoots and control loop saturation.
Deceleration	Description: Allows the user to limit the motor maximum deceleration. This function is available in speed control mode only.
The following values can be set: from 0 to 99990 rpm/s in steps of 10.	Note: The function is disabled when set to 0. This feature can be used to prevent excessive acceleration steps being applied to sensitive loads. It allows for smooth acceleration of loads and helps eliminate overshoots and control loop saturation.
Reference	Description: Allows the user to control the motor by an analog signal or through the keypad.
The following values can be set: Digital or Analog	Note: In analog reference mode, the analog reference is directly proportional to the Max speed setting. In digital reference mode, the reference speed is set in the 'Control Loop' menu using the keypad.

Max. Input Refer.	Description: Allows the user to select the input reference voltage that sets the max speed.
The following values can be set: ± 3.2 V to ± 10.0 V in steps of 0.1V	
Analog I Limit	Description: Allows the user to limit the current supplied by the drive independent of speed until the max set value is achieved. The max set current value is controlled using I limit reference.
The following values can be set: Enabled or Disabled.	Note: This function can be used each time it is necessary to limit the max torque supplied by the motor during machine cycles.
Max. I Limit Ref	Description: Allows the user to select the input reference voltage on I Limit reference input which allows the max set current to be supplied to the motor.
The following values can be set: 3.2 V to 10.0V in steps of 0.1V	Note: Set the selected value on the numeric control to obtain a direct correspondence.

5.4 CONTROL LOOPS PARAMETERS MENU



The first menu level can be accessed by pressing ENTER. The first level is characterized by the two <> arrows which indicate the possibility of scrolling the menu from right to left. To access the menu, press ENTER. When the parameter to be modified is reached, press + / - to increase or decrease the variables. To go to the next parameter, press ENTER. The parameter scanning is recursive. To exit the menu, press ESC. Keep on pressing ESC if the displayed parameter is not the first item of the menu. In order to save the modified parameter
See 'Save Parameters' in the Utility Menu.



SECTION 5: COMMANDS

5.4.1 DESCRIPTION OF CONTROL LOOPS PARAMETERS

5.4.1.1 SPEED LOOP PARAMETERS

Reference speed	Description: it is possible to modify the motor speed by means of + and – keys. The drive must be in digital reference mode.
Allowed values: 0 to the minimum of motor max speed (Motor menu) and Max speed (Drive menu) in steps of 1 rpm.	Note: For analog reference, this window has no functions. The value set is saved when a Parameter Save is performed.

Proportional gain	Description: Allows the user to set the speed loop proportional gain.
Allowed values: 0 to 32767 in steps of 1 unit	Note:

Integral gain	Description: Allows the user to set the speed loop Integral gain.
Allowed values: 0 to 32767 in steps of 1 unit	Note:

Speed Ref Filter	Description: Allows the user to low pass filter the speed reference by means of a low-pass digital filter.
Allowed values: 1Hz to 800Hz in steps of 1 Hz.	Note: The filter limits speed overshoots due to sudden variations of the reference signal.

Speed Error Filter	Description: Allows the user to limit the speed loop bandwidth by means of a low-pass digital filter on the compensated speed error (Speed loop output to torque loop).
Allowed values: 20Hz to 800Hz in steps of 1 Hz.	Note: This filter can reduce high frequency oscillations due to high gain conditions. High controller gains can be required when high inertia load are present on the shaft.

Analog Offset ref.	Description: Allows the user to correct for and cancel any analog offset at the speed reference input.
Allowed values: –50 to +50 in steps of 1 unit	Note:

5.4.1.2 CURRENT LOOP PARAMETERS

Refer. current	Description: Setting the drive to torque control mode, it is possible to set a digital current reference. The reference can be varied using the + and - keys of the front panel.
Allowed values: 0 to the max current value set in steps of 0.1 A.	Note: For analog reference mode, the window has no functions.


Motor Parameters RW	Description: This parameter represents the motor resistance (Entered in Motor Menu). The parameter cannot be modified here.
The following values can be set::: 0 to 30 Ohm in steps of 0.1 Ohm	Note:

Motor Parameters Lw	Description: This parameter represents the motor inductance (Entered in Motor Menu). The parameter cannot be modified here.
The following values can be set: 0 to 200 mH in steps of 100 μ H.	Note:

Current reference Filter	Description: Allows the user to low pass filter the current reference by means of a low-pass digital filter. This filter is equivalent to the Speed Error Filter detailed in 5.4.1.1
Allowed values: from 0 to 800 Hz in steps of 1 Hz.	Note:

Analog Ref. Offset	Description: Allows the user to correct and cancel any analog offsets in current reference input.
Allowed values: from -50 to +50 in steps of 1 unit	Note: This analog offset compensator is equivalent to that described in 5.4.1.1.

5.5 Enable menu



5.5.1 Description of Enable Menu

Drive Enabling	Description: With the drive Enable digital input active, the drive can be enabled from the keypad.
Allowed values: Drive Off & Drive On	Note: For this function to operate, the Drive Enable digital input must be active and Drive Enable set to local. See 5.3.1 Drive Enable.

5.6 DISPLAY VARIABLES MENU

Drive Enable < Display Variables > Utility

The first menu level can be accessed pressing ENTER. The first level is characterized by the two <> arrows which indicate the possibility of scrolling the menu from right to left. To access the menu, press ENTER. To go to the next parameter, press ENTER. The parameter scanning is recursive. To exit the menu, press ESC. Keep on pressing ESC if the displayed parameter is not the first item of the menu.

It is not possible to modify the parameters displayed inside this menu.

- Display Variables
- |
- Firmware Release
- Speed Reference [rpm]
- Detected Speed [rpm]
- Speed Error [rpm]
- BUS Voltage [V]
- +15 Voltage [V]
- 15 Voltage [V]
- Phase Shift
- R Regen Power [W]
- Heatsink Temp [deg]
- Current Limit [Apk]
- Max RR Duty [%]
- Checksum flash


5.6.1 Description of Display Variables menu

Firmware release	Description: Displays the version of Embedded software installed on the drive.
Speed Ref. [rpm]	Description: Indicates the speed reference value.
Detected speed [rpm]	Description: Indicates the motor measured speed. The function is also active when the drive is disabled.
Speed Error [rpm]	Description: Indicates the speed error between the reference and the measured speed.
BUS Voltage [V]	Description: Indicates the DC BUS voltage detected by the drive. This value is used for the soft-start and recovery circuit management.
+15 Voltage [V]	Description: Indicates the +15V logic voltage level detected by the drive.
-15 Voltage [V]	Description: Indicates the -15V logic voltage level detected by the drive.
Phase Shift	Description: Indicates the phase shift introduced to compensate the phase lag of the current loops at high motor shaft speed.
R Regen power [W]	Description: Indicates the power being dissipated in the recovery resistors. This calculation relies on the correct recovery resistance having been entered.
Heatsink Temp. [°C]	Description: Indicates the drive heatsink temperature. This value is used in the drive thermal management software.

<p>Current Limit [Apk]</p>	<p>Description: Indicates the current limit of the drive. Includes the limits introduced in the motor menu, drive menu, I_Limit analog input (if enabled. See 5.3.1 Analog I_Limit) IT Limiting (See 5.3.1 IT Protection) and thermal protection software of the drive.</p> <p>Note: The thermal protection software operates based on a thermal model of the drive. It accounts for the mode of operation (Stalled \leq 50rpm, running $>$ 50rpm), heatsink and drive losses. This software prevents the junctions of the power switches exceeding their maximum ratings.</p>
<p>MaxRR Duty [%]</p>	<p>Description: Indicates the maximum continuous duty cycle (%) that the drive will allow the recovery resistor to operate. This is based on the entered recovery resistor power and resistance parameters and the motor voltage.</p>
<p>Checksum flash</p>	<p>Description: Indicates the checksum calculated by the drive embedded software. If a discrepancy exists between the calculated and stored value, it may indicate that the embedded software has been corrupted. In this case, it is necessary to reload the embedded software.</p>

SECTION 5: COMMANDS

5.7 UTILITY MENU



The first menu level can be accessed pressing ENTER.
 The first and second levels are characterized by the two <> arrows which indicate the possibility of scrolling the menu from right to left.
 To access the menu, press ENTER.
 When the parameter to be modified is reached, press + / - to increase or decrease the variables
 To go to the following parameter, press ENTER. The parameter scanning is recursive.
 To exit the menu, press ESC.
 Keep on pressing ESC if the displayed parameter is not the first item of the menu.
 In order to save the modified parameters, see "Save Parameters" inside this menu.

NOTE: To access the "Analog out configuration", press enter, select the required variable using the < > keys and confirm by pressing ENTER. This variable is available on the analog output with the scaling indicated in the 'Configuration Analog Out' menu. The configuration can be saved using the "Save parameters" menu.

5.7.1 Description of Utility, Configuration Analog Out Sub Menu

<p>Analog Out Configuration</p>	<p>Description: Allows the user to configure the analog output with the required parameter. When this menu is accessed (By pressing Enter), the preset value is shown. Use the < and > keys to scroll through the menu. Press ENTER to select the required parameter and to exit the menu.</p>
<p>Zero Setting Analog Out</p>	<p>Description: Allows the user to set the Analog Out to zero. The output is kept to zero.</p>
<p>Speed Reference. [10V/Velmax]</p>	<p>Description: Configures the Analog Out with the Speed Reference.</p>
<p>Speed Error [10V/Velmax]</p>	<p>Description: Configure the Analog Out with the Speed Error.</p>
<p>Current Ref. [10V/Imax]</p>	<p>Description: Configures the Analog Out with the Current reference. The information can be useful to check the actual load applied to the drive and the motor.</p>
<p>I Limit [10V/100%]</p>	<p>Description: Configures the drive with I Limit (Current Limit)</p>
<p>U Phase El. Pos [20V p.p.]</p>	<p>Description: Configures the Analog Out with phase U electric position. ± 10 Volt output corresponds to phase U angular position between 0 and 360° electrical degrees. If a two-pole resolver is used, it is possible to determine the motor position directly through the analog output.</p>
<p>V Phase El. Pos [20V p.p.]</p>	<p>Description: Configures the Analog Out with phase V electric position. ± 10 Volt output corresponds to phase V angular position between 0 and 360° electrical degrees. If a two-pole resolver is used, it is possible to determine the motor position directly through the analog output.</p>
<p>U Phase Det. Cur. [10V/Imax]</p>	<p>Description: Configures the Analog Out to the instant value of the current supplied by phase U.</p>
<p>V Phase Det. Cur. [10V/Imax]</p>	<p>Description: Configures the Analog Out to the instant value of the current supplied by phase V.</p>

U Phase B.E.M.F. [10V/500V]	Description: Configures the Analog Out to the instant value of the B.E.M.F. on the motor phase U.
V Phase B.E.M.F. [10V/500V]	Description: Configures the Analog Out to the instant value of the B.E.M.F. on the motor phase V.
U Phase Voltage [10V/500V]	Description: Configure the Analog Out to the instant value of the voltage on Phase U (sum of B.E.M.F. and resistive drop).
V Phase Voltage [10V/500V]	Description: Configure the Analog Out to the instant value of the voltage on Phase V (sum of B.E.M.F. and resistive drop).
BUS Voltage [10V/1000V]	Description: Configure the Analog Out to the DC Bus voltage
Tachometric [Maxspeed/Scale]	Description: Configures the Analog Out to the instantaneous value of the motor speed.

5.7.2 Description of Utility, Parameter Sub menus


Save Parameters	Description: Allows the user to save drive configuration parameters to flash memory. Press ENTER to enable this function. A Save cannot be carried out if the drive is enabled. Once the Saving is complete, the drive is reset.
Reset Parameters	Description: Allows the user to restore all drive configuration parameters saved previously in the drive flash memory. Press ENTER to enable this function. Drive should be disabled. Once the restore is complete, the drive is reset.
Parameters Set Default	Description: Allows a default parameters set to be restored. All drives have the same default configuration. Press ENTER to enable this function. Drive should be disabled. Once the restore is complete, the drive is reset.

SECTION 5: COMMANDS

5.7.3 Description of UTILITY, Phasing & Save Program Sub Menu



CAUTION: *In this mode the motor can rotate a fraction of a revolution. The motor must be free to rotate to ensure phasing accuracy.*




<p>Phasing</p>	<p>Description: Allows the user to compensate any offset between the motor position and the feedback device (resolver or encoder) position on the motor shaft. If this is not completed, the rotor position used by the current control software may be incorrect.</p>
	<p>Operation:</p> <ol style="list-style-type: none"> 1. Set the drive to local Enable and apply the external drive enable signal 2. Press ENTER in the "Phasing" menu. 3. 'Wait for 'Positioned Motor' to appear on the display. 4. Once the drive has determined the offset between resolver/encoder and motor, it will be displayed in the 'Zero Search [±15] window. Note: For global motors, the value displayed will be outside the ±15 range indicated. 5. Press ENTER, 'Phasing End Push Enter' will be displayed. The value indicated will be written to the APHAPOS parameter of the Motor Menu. 6. Press ENTER again and the drive will return to the 'Utility' Sub Menu. <p>Note: the APHAPOS parameter can be used to manually correct the motor phasing</p>

<p>Save Program</p>	<p>Description: Allows the user to save the drive control program after the file has been downloaded through the Moog GUI. Press ENTER to enable this function. Drive should be disabled. Once the save is complete, the drive is reset.</p>
----------------------------	---

SECTION 5: COMMANDS

5.7.4 Description of UTILITY, OFFSET sub MENU



The first menu level can be accessed by pressing ENTER.
 The first level is characterized by the two < > arrows which indicate the possibility of scrolling the menu from right to left.
 To access the menu, press ENTER and enter the required password.
 Press + / - to increase or decrease the variables
 To go to the following parameter, press ENTER. The parameter scanning is recursive.
 To exit the menu, press ESC.
 Keep on pressing ESC if the displayed parameter is not the first item of the menu.
 In order to save the modified parameters, see "Save Parameters" in the "Utility" menu.




CAUTION: *The current offset calibration should only be carried out by skilled personnel.*



CAUTION: *Moog Variables contains parameters and functions that can be accessed only during system test and set-up. They are not accessible to the End User (OEM)*


5.8 Keyboard Lock Menu




5.8.1 Description of Keyboard Lock/Unlock Menu

Keyboard Lock/Unlock	Description: Allows the user to lock or unlock the keypad. The keypad is automatically locked when the drive is power up. To unlock the keyboard, press ENTER at Keyboard Lock and use the <, > keys to Unlock or Lock the Keyboard as required.
-----------------------------	---

5.9 FAULT MENU



5.9.1 Description of Fault Menu



The TROUBLESHOOTING Section provides information about Faults.

IGBT Fault	Description: Detects excess current or a short circuit condition in each of the 6 IGBTs of the output three-phase bridge.
IGBT Fault Recovery	Description: Detects excess current or short circuit condition in the recovery circuit IGBT.
Bus Overvoltage	Description: Detects a BUS overvoltage condition. The drive will disable. This can be due to a recovery resistance failure or the resistance value being too high for the application. The recovery circuit cannot dissipate the recovered energy from the motor.
Bus Undervoltage	Description: Detects a BUS undervoltage condition. The drive disables. The Bus undervoltage fault occurs if the DC bus falls by 25%.
Unstable Bus at DRIVE ON	Description: Detects the DC BUS ripple at drive power on with no power delivered to the motor. This fault could be due to an open fuse on the three-phase line.
No Bus Vbus =	Description: Detects the absence of the DC BUS. Fault occurs for a DC bus lower than 70 Volt (minimum default factory set value)
Bus/Mot. Voltage Incompatible	Description: Detects incompatible motor voltage setting with respect to the voltage detected on DC bus. E.g. > 400V DC bus and motor voltage parameter set to 230V.
Res. Rec. / Main Incompatible	Description: Indicates incorrect value for recovery resistance. Too low a resistance value (lower than the recommended one) can cause a recovery IGBT failure due to excessive current. A value higher than that recommended can prevent the drive dissipating peak motor recovered power.
System Error on Vbus Detects	Description: Indicates an anomaly in the measurement of the DC bus. Remove AC input. If the fault persists, the drive is damaged and should be returned for repair.
Flash - Error	Description: Indicates an error in accessing the

Default setting	parameters saved in the drive. This may be due to an access error. Reset the drive. If the fault persists re-enter the parameters and retry. If the fault still persists, the drive should be returned for repair.
Heatsink Fault	Description: Indicates a drive heatsink overtemperature. Check the drive cooling and that the fan is operating correctly.
Motor Fault OverTemperature	Description: Indicates a motor overtemperature. Verify that the motor is sized appropriately for the application.
Overcome Max Speed	Description: Indicates that the max speed set has been exceeded by more than 12%. Verify the operation of the control loops and that the motor is capable of applying sufficient braking torque to the load.
UVW Encoder Detection Error	Description: Indicates an error in the encoder signals for the motor phases. In the case of a first start up check that the wiring is made correctly. For a running system, check that no wires are cut and that the encoder is working properly.
Encoder pulses detection error	Description: Indicates an error in the encoder signals for the motor angular position. In the case of a first start up check that the wiring is made correctly. For a running system, check that no wires are cut and that the encoder is working properly.
Fault Resolver	Description: Indicates an error in the resolver feedback signals. In the case of a first start up check that the wiring is made correctly. For a running system, check that no wires are cut and that the resolver is working properly.
+15V supply fault	Description: Indicates that the +15 Volt internal logic supply is out of tolerance.
-15V supply fault	Description: Indicates that the -15 Volt internal logic supply is out of tolerance.
Fault Size	Description: Indicates that the control card has detected that it is connected to a new power stage of different size. To remove this fault, return the control

	card to the original power stage or save the new configuration.
Flash Error Checksum	Description: Indicates an internal memory error. Switch off and on the drive to verify the memory has been read correctly. Perform a Save. If the problem persists, the internal memory is damaged and should be returned for repair.

SECTION 6 CONTROL LOOPS**6.1 INTRODUCTION**

This section describes the drive control loops and contains instructions on how they can be optimized.

6.2 CURRENT LOOP

- The current control loop is based on a PI structure with additional compensation for motor electromotive force (B.E.M.F.).
- The control loop automatically adjusts the proportional and integral gains to set the appropriate frequency response once the motor resistance, motor inductance, and motor electromotive force (E1000) are entered.
- The algorithms allow the integral and proportional gains to be adjusted by entering data via the keypad or the Moog GUI. No drive instruments or test bench calibration is required.
- The loop structure compensates the phase shift introduced by the current sensors and interface circuits. This allows a zero phase shift and a “flat” phase response between 0 and approx. 800 Hz, independent of the motor attached.

6.3 SPEED LOOP

- The speed uses a simple PI structure.
- Through the VKI and VKP gains, the servo-system speed response can be adapted to suit the motor load.
- The control loop is updated at a frequency of 5 kHz.
- The bandwidth is limited internally, via software, to 400 Hz.

Details of how to tune the speed loop are given in Section 4.3.

6.4 ADDITIONAL CONTROL STRUCTURES

6.4.1 Soft-start Control

The drive continuously monitors the bus voltage. The softstart software controls softstart operation by reading the bus voltage and calculating the derivative. When the set threshold is reached or when internal capacitance are charged, the circuit closes the soft-start relay. The relay will remain closed until the DC bus falls by 25%.

If the bus voltage changes suddenly at drive enable, it is possible that a fault exists on the three-phase power supply (blown fuse, missing connection, or inadequate power supply). In this condition, an error will be reported by the drive and it will not enable.

6.4.2 Recovery resistor control circuit

The MicroDS is equipped with an internal recovery resistor of 120 Ω , 100W. An additional external resistor with the same characteristics can be attached externally if required.

By directly monitoring the DC bus, the drive can control the recovery circuit thresholds for different power supply voltages. No hardware calibration or setting is necessary.

The braking circuit control controls the recovery transistor gate drive signals to ensure the ratings of the recovery resistor are not exceeded while providing the maximum instantaneous recovery capability. This is achieved by allowing a longer on-time when the recovery first turns on and then reducing the on-time over time so as to maintain the continuous power rating of the resistor. This functionality is detailed in Section 5.

6.5 Additional Drive Data

6.5.1 Output current from the DC Bus connection

Drive Sizes	RMS Current	RMS Peak Current
3/11	3 A	6 A
6/22	6 A	12 A

Note: The Drive motor current is included in this current.

Tab 6.1 DC Bus Output Current Ratings

6.5.2 Max Recovery Current on MicroDS Drives

The following table lists the maximum value of the current and power that the recovery circuit is rated for. The recovery voltage is turn-on threshold $760 V_{DC}$ (on the DC Bus).

Drive Size	Recovery Current (A_{pk})	Recovery Resistor Power (W)
3/11	6.25 (12.5 with additional external Resistor)	50 (100W with additional external Resistor)
6/22	6.25 (12.5 with additional external Resistor)	100(200W with additional external Resistor)

Tab 6.2 DC Recovery Resistor Ratings

SECTION 7 TROUBLESHOOTING

7.1 INTRODUCTION

This section contains instructions on trouble shooting the controller.



Caution: *Repairs or modifications to the product by anyone other than a Moog authorized repair facility may create unsafe operating conditions and will invalidate the product warranty.*



WARNING: - *Do not attempt to repair or make internal adjustments to the controller. Lethal voltages are present and changes to factory calibration can result in serious equipment and/or personnel risk and void the equipment warranty. All faulty items of this equipment must be returned to Moog Service Centres for maintenance and repair.*



WARNING: *Lethal voltages ($\geq 790V_{dc}$) remain present within this equipment when the mains power is removed. It is recommended to refrain from commencing any servicing, maintenance, repair or upgrading of this equipment until at least **five minutes** after power shutdown. It is further recommended to measure the voltage level at all high voltage terminals before commencing any such activities, to ensure that no lethal voltages are present.*

7.2 Faults on drive power supply circuit

Problem	Although the 24 Volt power is supplied, fan does not work and the display is not lit:
Suggestion	Check that the 24 Volt power is properly supplied
Possible cause	The 24 Volt power supply is broken. Contact Moog Service

Problem	Although the 24 Volt power and mains power is applied, drive does not softstart
Suggestion	Check that the mains is connected correctly. Check the reported DC bus voltage on the display. If the expected voltage is not displayed, the drive monitoring circuit is damaged.
Possible cause	Internal monitoring circuit damaged. Contact Moog Service

Problem	The drive indicates a Fault on the +/- 15 V internal power supplies
Suggestion	Disconnect both the encoder cable and the Enable cable.
Possible cause	If the problem persists, a failure is present on the internal power supply section. Contact Moog Service.

Problem	Although the 24 Volt power is supplied and the fan operates, the display remains blank
Suggestion	Check the reset digital input. Disconnect cable to J2B.
Possible cause	Reset digital input active. If problem persists, contact Moog Service.

7.3 Faults on output section

Problem	The drive signals an IGBT Fault (short circuit or overload)
Suggestion	Disconnect the motor power supply cable.
Possible cause	<p>A) If the problem persists, part of the power section may have failed. Unplug the drive from the power line, then, using a multimeter in ohmmeter mode, check whether a short circuit exists in the power section. Use the following instructions to check the power stage.</p> <ol style="list-style-type: none"> 1) Place the positive (red) test probe on the + DC terminal; Check that there is no short circuit between the motor U, V, and W phases and this terminal. 2) Repeat the same operation: Place the positive (red) test prod on the - DC terminal; Check that there is no short circuit between the motor U, V, and W phases and this terminal. <p>In case of a short circuit between the terminals, the IGBT power module is damaged. Return the drive to Moog Service for repair.</p> <p>B) If the problem does not persist, it may be due to the motor cables or to the motor itself:</p> <ol style="list-style-type: none"> 1) Disconnect the cable from the motor and check that the motor cables are not shorted. 2) Check that the motor resistance, detected between the phases, is the same as that indicated in the catalogue.
Note	Shielded motor cables longer than 10-15 meters with high capacitance can cause disturbances that can be read as overload or short circuit by the drive. In case of concerns regarding cable quality, contact Moog Service.

7.4 Faults on feedback section

Problem	The drive indicates an encoder pulses fault
Suggestion	<ol style="list-style-type: none"> 1) Check the Encoder/Resolver parameters against the settings in the drive 2) Check that the encoder pulses number set in the drive corresponds to the actual encoder pulse count. 3) Check the connections between Encoder/Resolver and drive. 4) Check that the problem is not present on another motor.
Possible cause	If the problem persists, there is a fault in the Encoder data acquisition section inside the drive. To solve this problem, contact Moog Service.

Problem	The drive indicates an encoder PHASES pulses Fault
Suggestion	<ol style="list-style-type: none"> 1) Check the Encoder/Resolver parameters against the settings in the drive 2) Check that the set motor poles set corresponds to the actual motor poles. 3) Check the connections between Encoder/Resolver and drive. 4) Check that the problem is not present on another motor.
Possible cause	If the problem persists, there is a fault in the Encoder data acquisition section inside the drive. To solve this problem, contact Moog Service.
Note	<p>The encoder has two different sections:</p> <ol style="list-style-type: none"> 1) The first section generates the pulses for the acquisition of motor position and speed, i.e.: 1024, 2048, etc. 2) The second section provides the drive with information regarding the position inside the motor electric loop and is synchronous with the motor pole pairs. <p>If a resolver is used for feedback, the drive interface converts the information received into the two encoders. For the purpose of controlling the drive, there is no difference between encoder feedback and resolver feedback.</p>

7.5 Control loops trouble

Problem	The motor is excessively noisy when enabled.
Suggestion	<ol style="list-style-type: none"> 1) Check that motor and drive cables are properly shielded. Route the power and feedback cables in different and insulated conduits, particularly when cables runs are longer than 15 meters. 2) Check that the cables connecting the CNC to the drive are properly shielded. Improper shielding can cause noise on these cables when the axis is enabled. 3) Check that the noise is not due to Vki and VKP gains. Reduce the set values to check their influence. If the gains are incorrect, this can cause instability in the system. <ol style="list-style-type: none"> a) Verify the output encoder pulse number. Replace the motor with one having higher encoder pulse count if possible. Higher angular position resolution will allow increased gain settings. b) Reduce the system frequency response by means of the filter on the speed error until noise is reduced. Do not reduce the value significantly below 100 Hz to avoid system instability. 4) Check that the grounding is as shown in Section 3 (Electromagnetic Compatibility)
Possible cause	If the problem persists, Contact Moog Service.

Problem	The motor oscillates (at high frequencies or hums)
Suggestion	<ol style="list-style-type: none"> 1) Check that mechanical transmission is rigid, that belts are not slack and there are no other mechanical parts, which can cause oscillation. 2) Check that VKI and VKP gains are properly set. Increasing these values should modify the oscillation frequency. If this does not work, try to identify the oscillation frequency with an oscilloscope and reduce it with a Notch filter.
Possible cause	If the problem persists it could be due to a fault in the internal control section or in the feedback section. Contact Moog Service.

Problem	The motor oscillates at low frequency (less than 10 Hz)
Suggestion	Check the speed loop and CNC position loop gains
Possible cause	If the problem persists it could be due to a fault in the internal control section, in the feedback section, or in the CNC. Contact Moog Service.

Appendix A : Warranty

MicroDS Drives, together with all options and accessories are covered under warranty for a period of 12 months.

Conditions for Warranty validity are the following:

- a) The device has been installed according to the instructions provided in this manual
- b) The device has not been tampered with or operated improperly (traces of water, humidity, incorrect wiring, etc.).
- c) The Drive Identification LABEL is not damaged nor counterfeited.

Appendix B : Motors technical data

The following tables provide data for some of the motors that can operate with the MicroDS drives. If a motor is not mentioned, it is possible to find the relevant data from;

- The relevant Moog Motor Catalogues
- By Contacting a Moog Service Centers.

Motor	Size	No. of Poles	Speed (RPM)	Peak Current (A)	BEFM (E1000)	Resistance (Ohm)	Inductance (mH)
FAST00V2100	00	6	10.000	7.8	17.5	14.6	11.3
FAST00V4100	00	6	10.000	9.2	27.8	10.4	9.9
FAST0V2060	0	6	6.000	8.3	26.6	18.3	34.5
FAST0V4060	0	6	6.000	11.9	39.3	12.9	31.4
FAST0V8060	0	6	6.000	19.8	38.7	4.9	14.9
FAST1V2030	1	6	3.000	11.3	75.5	13.0	61.6
FAST1V2060	1	6	6.000	22.0	38.7	3.4	16.8
FAST1V4030	1	6	3.000	21.7	70.7	4.0	25.1
FAST1V4045	1	6	4.500	19.6	55.6	2.6	15.8
FAST1V6030	1	6	3.000	24.6	83.4	3.3	23.2
FAST2V2030	2	6	3.000	23.8	89.4	3.4	22.0

Note: For the FAST00 motors, use the data in this manual, rather than the data in the motor Catalogue.

Tab B.1 FAST V Brushless Motors (6 motor poles, high voltage)

Motor	Size	No. of Poles	Speed (RPM)	Peak Current (A)	BEFM (E1000)	Resistance (Ohm)	Inductance (mH)
FASN0V3030	0	6	3.000	9.1	37.3	18.9	42.0
FASN0V6030	0	6	3.000	9.5	62.8	21.2	55.8
FASN1V2030	1	6	3.000	10.5	81.6	13.4	58.9
FASN1V4030	1	6	3.000	16.6	97.3	6.7	35.6
FASN7V2030	7	6	3.000	9.8	104.5	14.6	65.0
FASN7V4030	7	6	3.000	21.7	94.2	3.9	24.5
FASN2V2030	2	6	3.000	21.3	100.0	5.9	27.3
FASN3V1030	3	6	3.000	24.5	114.8	2.1	23.9

Tab B.2 FASN/FAEN V Brushless Motors (6 motor poles, high voltage)

Motor	Current Peak (A)	BEMF (E1000)	Resistance (Ohm)	Inductance (mH)	ID (A)	SG
FASY-63-V	9	50	8.0	34.8	0.8	16
FASY-63-F	9	50	8.0	34.8	0.8	16
FASY-80-V	22	56	2.8	9.5	2.6	1.8
FASY-80-F	22	56	2.8	9.5	2.6	1.8
FASY-90-V	22	55	1.3	5.5	4.0	1.7

Tab B.3 Asynchronous Vectorial Motors FASY (4 motor poles, high voltage)

Note:

- For all the FAS Y motors, the following characteristics are common:
 - 4 motor poles,
 - nominal voltage 400 Volt,
 - speed 3000 rpm.
- The BEMF parameter is used to divide the working areas between constant torque and constant power.

Motor	Nom. Voltage	Pole N°	Speed (RPM)	Peak Current (A)	BEMF (E1000)	Resistance (Ohm)	Inductance (mH)
G424-806	220 V	12	3500	28.0	53.8	0.9	3.5
G423-804	220 V	8	3900	16.3	54.4	4.1	8.9
G423-604	220 V	8	4800	12.4	45.3	5.1	10.3
G463-415	400 V	8	6200	11.3	43.0	9.5	16.1
G463-617	400 V	8	4800	11.3	71.8	13.0	24.8
G464-417	400 V	12	5500	18.4	36.1	2.9	7.2
G464-617	400 V	12	4300	18.4	69.4	3.9	12.0
G464-817	400 V	12	3300	28.3	86.5	2.3	8.8
G465-417	400 V	12	4000	28.3	88.9	1.6	9.8

Tab B.4 Brushless Motor G400

Note:

- All Global motors use a two pole resolver
- The resolver is mechanically locked in the rear of the motor. Use the Phasing function in the Utility Menu to determine the value of APHAPOS.
- The resolver SIN and SIN (minus) signals should be swapped for correct operation. Resolver wiring is detailed in Section 1.

Appendix C : Special Motors

The MicroDS drive can directly drive FC series low speed special motors.

Motor	Nom. Voltage	Pole N°	Speed (RPM)	Peak Current (A)	BEFM (E1000)	Resistance (Ohm)	Inductance (mH)
290 FCV 1 054	290	12	320	25.3	903	6.5	36.6

Tab C.1 Brushless FC (12 motor poles, High voltage 400 Volt)

Note:

To increase the effective system resolution at very low speed, it is possible to scale some system parameters. This is detailed in the following table:

Condition	Resolver Poles	Motor Poles	Speed
a) Real Data	6	12	100
a) Scaled Value	2	4	300
b) Real Data	12	12	100
b) Scaled Value	2	2	600

Tab C.2 FC Motor Parameter Scaling

The effective speed in the Real and Scaled Data remains the same as the real speed.

C27159-001 Revision B, June 2012

Any suggestions, corrections and comments should be sent to:

Moog Italiana S.r.l.
Electric Division
Via Avosso 94
16015 Casella (Genova)
Italy

Moog Inc.,
East Aurora,
New York 14052,
USA.

Moog GmbH,
Hans Klemm Straße.28,
D-71034 Boblingen,
Germany.

Moog reserves the right to alter any data or technical feature without prior notice.